AT Command Manual

WISMO218 Wireless Standard MOdem

WA_DEV_W218_UGD_003
004
September 10, 2009

SIERRA WIRELESS
HEART OF THE WIRELESS MACHINE®

Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the Sierra Wireless modem are used in a normal manner with a well-constructed network, the Sierra Wireless modem should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Sierra Wireless accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the Sierra Wireless modem, or for failure of the Sierra Wireless modem to transmit or receive such data.

Safety and Hazards

Do not operate the Sierra Wireless modem in areas where blasting is in progress, where explosive atmospheres may be present, near medical equipment, near life support equipment, or any equipment which may be susceptible to any form of radio interference. In such areas, the Sierra Wireless modem **MUST BE POWERED OFF**. The Sierra Wireless modem can transmit signals that could interfere with this equipment. Do not operate the Sierra Wireless modem in any aircraft, whether the aircraft is on the ground or in flight. In aircraft, the Sierra Wireless modem **MUST BE POWERED OFF**. When operating, the Sierra Wireless modem can transmit signals that could interfere with various onboard systems.

Note: Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. Sierra Wireless modems may be used at this time.

The driver or operator of any vehicle should not operate the Sierra Wireless modem while in control of a vehicle. Doing so will detract from the driver or operator's control and operation of that vehicle. In some states and provinces, operating such communications devices while in control of a vehicle is an offence.

Limitations of Liability

This manual is provided “as is”. Sierra Wireless makes no warranties of any kind, either expressed or implied, including any implied warranties of merchantability, fitness for a particular purpose, or noninfringement. The recipient of the manual shall endorse all risks arising from its use.

The information in this manual is subject to change without notice and does not represent a commitment on the part of Sierra Wireless. SIERRA WIRELESS AND ITS AFFILIATES SPECIFICALLY DISCLAIM LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE OR ANTICIPATED PROFITS OR REVENUE ARISING OUT OF THE USE OR INABILITY TO USE ANY SIERRA WIRELESS PRODUCT, EVEN IF SIERRA WIRELESS AND/OR ITS AFFILIATES HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

Notwithstanding the foregoing, in no event shall Sierra Wireless and/or its affiliates aggregate liability arising under or in connection with the Sierra Wireless product, regardless of the number of events, occurrences, or claims giving rise to liability, be in excess of the price paid by the purchaser for the Sierra Wireless product.

Copyright

© 2009 Sierra Wireless. All rights reserved.

Trademarks

AirCard® and “Heart of the Wireless Machine®” are filed or registered trademarks of Sierra Wireless. Watcher® is a trademark of Sierra Wireless, registered in the European Community. Sierra Wireless, the Sierra Wireless logo, the red wave design, and the red-tipped antenna are trademarks of Sierra Wireless.

wavecom®, OPEN AT, ®, inSIM®, “YOU MAKE IT, WE MAKE IT WIRELESS®”, WAVECOM®, WISMO®, Wireless Microprocessor®, Wireless CPU®, Open AT® are filed or registered trademarks of Wavecom S.A. in France and/or in other countries.

Windows® is a registered trademark of Microsoft Corporation.

QUALCOMM® is a registered trademark of QUALCOMM Incorporated. Used under license.

Other trademarks are the property of the respective owners.

Contact Information

Sales Desk:	Phone:	1-604-232-1488
	Hours:	8:00 AM to 5:00 PM Pacific Time
	E-mail:	sales@sierrawireless.com
Post:	Sierra Wireless 13811 Wireless Way Richmond, BC Canada V6V 3A4	
Fax:	1-604-231-1109	
Web:	www.sierrawireless.com	

Consult our website for up-to-date product descriptions, documentation, application notes, firmware upgrades, troubleshooting tips, and press releases:

www.sierrawireless.com

Revision History

Revision	Date	Update
001	April 24, 2009	Creation
002	June 4, 2009	Update
003	July 7, 2009	Update
004	September 10, 2009	Update

Contents

1. AT COMMANDS DESCRIPTION 11

2. 3GPP TS 27.005 COMMANDS 12

General Configuration Commands 12

+CSMS Select Messages Service 12
+CPMS Preferred Messages Storage 13
+CMGF Messages Format 13

Message Configuration Commands 14

+CSCA Service Center Address 14
+CSCB Select Cell Broadcast Messages Types 15
+CSMP Set Text Mode Parameters 16
+CSDH Show Text Mode Parameters 16
+CSAS Save Settings 17
+CRES Restore Settings 18

Message Receiving and Reading Commands 18

+CNMI New Messages Indication to TE 18
+CNMA New Message Acknowledgement to ME/TA 20
+CMGL List Messages 22
+CMGR Read Message 23

Message Sending and Writing Commands 25

+CMGS Send Message 25
+CMSS Send Message from Storage 26
+CMGW Write Message to Memory 27
+CMGD Delete Message 27

SMS and CBM Unsolicited Result Codes 28

+CMTI Received SMS indication 28
+CMT Received SMS indication 29
+CBM Received CBM indication 30
+CDS Received status report (SR) indication 30

+CMS ERROR Message Service Failure Result Code 30

3. 3GPP TS 27.007 COMMANDS 32

General Commands 32

+CGMI Request Manufacturer identification 32
+CGMM Request Model Identification 32
+CGMR Request Revision Identification 33
+CGSN Request product serial number identification 33
+CSCS Select TE character set 33

+CIMI Request international mobile subscriber identity 34
+CMUX Multiplexing mode 34

Call Control Commands 37

+CSTA Select type of address 37
+CMOD Call mode 38
+CHUP Hang-up call 38
+CBST Select bearer service type 38
+CRLP Radio link protocol 39
+CR Service reporting 40
+CEER Extended error report 41
+CRC Cellular result codes 43
+CVHU Voice Hang-up Control 44

Call Control Result Code 44

+CR Service reporting 44
+CRING Ring indication 45

Network Service Related Commands 46

+CNUM Subscriber number 46
+CREG Network registration 47
+COPS Operator Selection 48
+CLCK Facility lock 50
+CPWD Change password 51
+CLIP Calling line identification presentation 52
+CLIR Calling line identification restriction 53
+COLP Connected line identification presentation 54
+CCFC Call forwarding number and conditions 55
+CCWA Call waiting 56
+CHLD Call related supplementary services 58
+CTFR Call deflection 58
+CUSD Unstructured supplementary service data 59
+CAOC Advice of Charge 60
+CSSN Supplementary service notifications 61
+CLCC List current calls 61
+CPOL Preferred PLMN list 63
+CPLS Selection of preferred PLMN list 64
+COPN Read operator names 65

Network Service Related Result Codes 65

+CREG Network registration 65
+CLIP Calling Line Identification Presentation 66
+COLP Connected line identification presentation 67
+CCWA Calling Line Identification Presentation 67
+CUSD Unstructured supplementary service data 68
+CCCM Current Call Meter 69
+CSSI Supplementary service notification 70
+CSSU Supplementary service notification 70

Control and Status Commands **71**
+CPAS Phone activity status 71
+CFUN Set phone functionality 71
+CPIN Enter PIN 72
+CPWC Power class 74
+CSQ Signal Quality 75
+CMEC Mobile Termination control mode 75
+CIND Indicator control 76
+CMER Mobile Termination event reporting 77
+CPBS Select phonebook memory storage 78
+CPBR Read phonebook entries 80
+CPBF Find phonebook entries 82
+CPBW Write phonebook entry 83
+CCLK Clock 83
+CSIM Generic SIM access 84
+CRSM Restricted SIM access 84
+CRSL Ringer sound level 86
+CLVL Loudspeaker volume level 86
+CMUT Mute control 87
+CACM Accumulated call meter 88
+CAMM Accumulated call meter maximum 88
+CPUC Price per unit and currency table 89
+CCWE Call Meter maximum event 89
+CLAN Set Language 90
+CSVM Set Voice Mail Number 90
+CRMP Ring Melody Playback 91
+CLAC List all available AT commands 92
+CALA Set alarm time 92
+CALD Delete alarm 94

Control and Status Result Codes **94**
+CCWV Call Meter warning value 94
+CIEV Indicator event report 95

Mobile Termination Error Control **95**
+CMEE Report Mobile Equipment error 95

Mobile Termination Error Result Code **96**
+CME ERROR 96

Commands for Packet Domains **98**
+CGDCONT Define PDP Context 98
+CGQREQ Quality of Service Profile (Requested) 100
+CGQMIN Quality of Service Profile (Minimum acceptable) 102
+CGATT PS attach or detach 103
+CGACT PDP context activate or deactivate 103
+CGCMOD PDP Context Modify 104
+CGDATA Enter data state 104
+CGPADDR Show PDP address 106

+CGCLASS GPRS mobile station class 107
+CGREG GPRS network registration status 107
+CGSMS Select service for MO SMS messages 109
Request Packet Domain service 'D' 109
Request Packet Domain IP service 'D' 110
+CGEREP Packet Domain event reporting 110

Packet Domains Result Codes 111

+CGREG registration status 111

4. ITU-T V25.TER COMMANDS 113

Call Control 113

A Answer 113
D Dial 113
D> Direct dialling from phone book 114
H Hang up 114
L Monitor speaker loudness 115
M Monitor speaker mode 115
O Online 116
P Pulse dialing 116
S0 Automatic Answer 116
S6 Pause before blind dialing 117
S7 connection completion timeout 117
S8 Comma dial modifier 118
S10 Automatic disconnect delay 118
T Tone dialing 119

General TA Control Commands 119

A/ Repeat last command 119
I Identification information 119
Z Reset default configuration 120
&F Factory defined configuration 121
+GCAP Complete capabilities list 123
+GMI Manufacturer identification 124
+GMM Model identification 124
+GMR Revision identification 124
+GSN Serial number identification 125

TA-TE Interface Commands 125

E Echo 125
Q Result code suppression 126
S3 Line termination character 126
S4 Response formatting character 127
S5 Line editing character 127
V TA response format 128
X Result code selection and call progress monitoring 128
&C DCD behaviour 129
&D DTR behaviour 129

+IPR Fixed TE rate 130
+ICF TE-TA character framing 130
+IFC TE-TA local flow control 131

Result codes 132

5. HAYES COMMANDS 134

Standard Hayes Commands 134

B Communication option 134
N Negotiate Handshake 134
S1 Ring Count 135
S2 Escape character 135
S11 DTMF Dialling Speed 135
S95 Windows XP compatibility 136
W Extended Result code 136

Advanced Hayes Commands 136

&K Extended Flow control option 136
&S DSR option 137
&V Configuration profile 137
&W Store Active profile 138

6. TIA IS-101 COMMANDS 140

+VTS DTMF and Tone Generation 140

+VTD Tone Duration 141

+VGR Receive Gain Selection 141

+VGT Transmit gain selection 142

+VIP Initialize voice parameter 143

7. TIA578A COMMANDS 144

General Commands 144

+FMI Manufacturer identification 144
+FMM Model identification 144
+FMR Revision identification 144

Capabilities Identification and Control 145

+FCLASS Model identification 145
+FTH HDLC transmit 145
+FRH HDLC receive 146
+FTM Facsimile transmit 146
+FRM Facsimile receive 147

8. PROPRIETARY AT COMMANDS 148

Capabilities Identification and Control 148
#CLS Service class 148

Flow Control Command 148
&R RTS/CTS option 148

Manufacturer Tests Command 149
+CPOF Power off 149
*PSSSURC Supplementary Services notification 149
+PSSLEEP Power Management control 150

SIM Toolkit Command and Result Codes 151
*PSSTKI SIM Toolkit interface configuration 151
*PSSTK SIM Toolkit control 152

CPHS Proprietary Commands 155
*PSVMWN Voice Message Waiting Notification 155
*PSALS Alternate Line Service 156
*PSDCIN Diverted Call Indicator Notification 157
*PSMBNB Mailbox Number 158
*PSCSP Customer Service Profile 159
*PSINFN Information number 160

General Purpose Proprietary Commands 162
*PSPRAS Pin Remaining Attempt Status 162
*PSSEAV Service Availability 163
+PSSREP Mobile start-up reporting 164
*PSCHRU Channel registration URC 165
+PSTAT tool detection enable 166
*PSRDBS Radio band settings 167
*PSADC A/D Convert info 168
+PSRIC RI behaviour 169
+WMGPIO GPIO access 170
+WMGPIOCFG GPIO configuration 171
+WMPWM PWM and buzzer configuration 172
+SIDET Sidetone 173
+WMECHO Echo Cancellation and Noise Reduction 174
+WSVN IMEI Software Version Number 175
+WMSN Serial number 175

Call and Network Proprietary Commands 176
*PSCSCN Call state change notification 176
+CNAP Command: Calling Name Presentation 181
*PSFSNT Field strength notification 182
*PSCSSC Call successful control 183
*PSCCDN Call connection and disconnection notification 184

1. AT Commands Description

This manual presents detailed information about the AT command set used with the WISMO218.

2. 3GPP TS 27.005 Commands

General Configuration Commands

+CSMS Select Messages Service

Description	Command	Possible Response(s)
Select messages service	+CSMS=<service>	+CSMS: <mt>,<mo>,<bm> OK +CMS ERROR: <err>
Get current service and settings	+CSMS?	+CSMS: <service>,<mt>,<mo>,<bm> OK +CMS ERROR: <err>
Get supported services	+CSMS=?	+CSMS: (list of supported <service>s) OK +CMS ERROR: <err>

Parameters

<service>	Description
0 (default)	3GPP TS 23.040 and 3GPP TS 23.041
1	3GPP TS 23.040 and 3GPP TS 23.041 (the requirement of <service> setting 1 is mentioned under corresponding command descriptions)

<mt>, <mo>, <bm>	Description
0	Type not supported
1 (default)	Type supported

zzzzClarification

<service> = 1 shall be used only on dual OS platforms i.e when TE is the only SMS client (SMS are only routed to TA in this case)

<service> = 0 shall be used by default.

The <service> parameter is automatically saved in non-volatile memory and restored to the default value by AT&F command.

+CPMS Preferred Messages Storage

Description	Command	Possible Response(s)
Select memory storage	+CPMS=<mem1>[,<mem2>[,<mem3>]]	+CPMS: <used1>,<total1>,<used2>,<total2>,<used3>,<total3> OK +CMS ERROR: <err>
Get current storage status	+CPMS?	+CPMS: <mem1>,<used1>,<total1>,<mem2>,<used2>,<total2>, <mem3>,<used3>,<total3> OK +CMS ERROR: <err>
Get supported storages	+CPMS=?	+CPMS: (list of supported <mem1>s),(list of supported <mem2>s),(list of supported <mem3>s) OK +CMS ERROR: <err>

Parameters

<memx>	Description
"SM"	Only "SM" storage is supported "BM", "ME", "MT", "TA", "SR" memory locations are not supported

<usedx>, <totalx>	Description
Integer type	Computed value

+CMGF Messages Format

Description	Command	Possible Response(s)
Select message format	+CMGF=[<mode>]	OK +CMS ERROR: <err>
Get current format	+CMGF?	+CMGF: <mode> OK
Get supported formats	+CMGF=?	+CMGF: (list of supported <mode>s) OK

<mode>	Description
0 (default)	PDU mode

<mode>	Description
1	Text mode
Omitted	Use previous value

Clarification

+CMGF parameter is automatically saved into non-volatile memory.

The <mode> parameter is restored to default value by AT&F command.

Message Configuration Commands

+CSCA Service Center Address

Description	Command	Possible Response(s)
Update SMSC address	+CSCA=<sca>[,<tosca>]	OK +CMS ERROR: <err>
Get current format	+CSCA?	+CSCA: <sca>,<tosca> OK +CMS ERROR: <err>
Get supported formats	+CSCA=?	OK +CMS ERROR: <err>

Parameters

<sca>	Description
String type	SC address Address-Value

<tosca>	Description
Integer type	SC address Type-of-Address

Clarification

This command reads and writes the service center address in EF-SMSP (U)SIM file.

If the SCA is not readable or empty, read command returns an empty string.

At switch on, the SCA is read on (U)SIM to have a default SCA for send and write command in text mode. (In PDU mode, SCA can be provided in PDU).

Service Center Address is reset on switch on and is read on SIM on first PC connection after switch on.

See data stored by +CSAS for default values.

+CSCB Select Cell Broadcast Messages Types

Description	Command	Possible Response(s)
Select CBM types	+CSCB=[<mode>[,<mids>[,<dcss>]]]	OK +CMS ERROR: <err>
Get current values	+CSCB?	+CSCB: <mode>,<mids>,<dcss> OK +CMS ERROR: <err>
Get supported modes	+CSCB=?	+CSCB: (list of supported <mode>s) OK +CMS ERROR: <err>

Parameters

<mode>	Description
0	Message types specified in <mids> and <dcss> are accepted
1	Message types specified in <mids> and <dcss> are not accepted

<mids>	Description
String type	all different possible combinations of CBM message identifiers (refer <mid> in 27.005)

<dcss>	Description
String type	all different possible combinations of CBM data coding schemes (refer <dcs> in 27.005) Default value: no DCS accepted

Clarification

All the <dcss> values can be accepted or up to 5 different <dcss> values can be accepted.

Ranges are not supported for <mids> and <dcss>, i.e notation "0,1,5,320-478,922" is not allowed for <mids> and notation "0-3,5" is not allowed for <dcss> .

Up to 15 different <mids> values can be accepted.

AT+CSCB=1 means all <dcss> are accepted but this command has no effect on the list of the <mids> accepted. To modify those lists: use before the AT+CSCB=0 command to select no mid and no dcs, and after this operation, add some dcs or mid to the current lists.

AT+CSCB=0,<mids> adds the <mids> values in the <mids> current list handled by the mobile.

AT+CSCB=0,,<dcss> adds the <dcss> values in the <dcss> current list handled by the mobile.

If AT+CSCB=0,"<value>" is received while the list of <mids> is full, OK is returned and new value is not added.

AT+CSCB=1,<mids> removes the <mids> values in the <mids> current list handled by the mobile.
AT+CSCB=1,,<dcss> removes the <dcss> values in the <dcss> current list handled by the mobile.

AT+CSCB? can only display an enabled list, so <mode> = 0 is returned.

+CSMP Set Text Mode Parameters

Description	Command	Possible Response(s)
Select SM parameters	+CSMP=[<fo>[,<vp>[,<pid>[,<dcs>]]]]	OK +CMS ERROR: <err>
Get current values	+CSMP?	+CSMP: <fo>,<vp>,<pid>,<dcs> OK +CMS ERROR: <err>
Test if command is supported	+CSMP=?	OK +CMS ERROR: <err>

Parameters

<fo>, <vp>, <pid>, <dcs>	Description
Integer type	Refer to 27.005 for description

Clarification

The enhanced validity period format ($(EVPF)$, see [23.040]) is not supported.

<fo> is only for SMS-DELIVER, SMS-SUBMIT or SMS-STATUS-REPORT.

See data stored by +CSAS for default values.

+CSMP parameters are automatically saved in non-volatile memory and restored to default values by AT&F command.

+CSDH Show Text Mode Parameters

Description	Command	Possible Response(s)
Select header presentation	+CSDH=[<show>]	OK +CMS ERROR: <err>
Get current status	+CSDH?	+CSDH: <show> OK +CMS ERROR: <err>

Description	Command	Possible Response(s)
Get supported values	+CSDH=?	+CSDH: (list of supported <show>s) OK +CMS ERROR: <err>

Parameters

<show>	Description
0	Do not show header values
1	Show the values in result codes
Omitted	Use previous value

+CSAS Save Settings

Description	Command	Possible Response(s)
Save SM service settings	+CSAS=[<profile>]	OK +CMS ERROR: <err>
Get the list of available profiles	+CSAS=?	+CSAS: (list of supported <profile>s) OK +CMS ERROR: <err>

Parameters

<profile>	Description
0	Save SM service settings in profile 0
1	Save SM service settings in profile 1
Omitted	Use previous value

Clarification

Parameter stored by +CSAS

Command	Parameter name
+CSCA	<sca>
+CSCA	<tosca>
+CSMP	<fo>

Command	Parameter name
+CSMP	<vp>
+CSMP	<pid>
+CSMP	<dcs>

+CRES Restore Settings

Description	Command	Possible Response(s)
Restore SM service settings	+CRES=[<profile>]	OK +CMS ERROR: <err>
Get the list of available profiles	+CRES=?	+CRES: (list of supported <profile>s) OK +CMS ERROR: <err>

Parameters

<profile>	Description
0	Restore SM service settings from profile 0
1	Restore SM service settings from profile 1

Message Receiving and Reading Commands

+CNMI New Messages Indication to TE

Description	Command	Possible Response(s)
Select procedure for received messages	+CNMI=[<mode>[,<mt>[,<bm>[,<ds>[,<bfr>]]]]]	OK +CMS ERROR: <err>
Get current values	+CNMI?	+CNMI: <mode>,<mt>,<bm>,<ds>,<bfr> OK +CMS ERROR: <err>
Get supported values	+CNMI=?	+CNMI: (list of supported <mode>s),(list of supported <mt>s),(list of supported <bm>s),(list of supported <ds>s),(list of supported <bfr>s) OK +CMS ERROR: <err>

Parameters

<mode>	Description
0 (default)	Buffer unsolicited result codes in the TA. When TA result code buffer is full: - The oldest indication is discarded and replaced with the new one when +CSMS=0 - All indications are buffered when +CSMS=1
1	Discard indication and reject new received message unsolicited result codes when TA-TE link is reserved (e.g. in on-line data mode). Otherwise forward them directly to the TE. Not supported for CBM messages.
2	Buffer unsolicited result codes in the TA when TA-TE link is reserved (e.g. in on-line data mode) and flush them to the TE after reservation. Otherwise forward them directly to the TE

<mt>	Description
0 (default)	No SMS-DELIVER indications are routed to the TE
1	If SMS-DELIVER is stored into ME/TA, indication of the memory location is routed to the TE using unsolicited result code: +CMTI
2	SMS-DELIVERs (except class 2 messages and messages in the message waiting indication group (store message)) are routed directly to the TE using unsolicited result code: +CMT
3	Class 3 SMS-DELIVERs are routed directly to TE using unsolicited result codes defined in <mt>=2. Messages of other data coding schemes result in indication as defined in <mt>=1

<bm>	Description
0 (default)	No CBM indications are routed to the TE
2	New CBMs are routed directly to the TE using unsolicited result code: +CBM

<ds>	Description
0 (default)	No SMS-STATUS-REPORTs are routed to the TE
1	SMS-STATUS-REPORTs are routed to the TE using unsolicited result code: +CDS

<bfr>	Description
0 (default)	TA buffer of unsolicited result codes defined within this command is flushed to the TE when <mode> 1...3 is entered (OK response shall be given before flushing the codes).
1	TA buffer of unsolicited result codes defined within this command is cleared when <mode> 1...3 is entered

Clarification

TA result code buffer is in volatile memory. Messages may get lost if the power of ME/TA is switched off before codes are sent to TE. Thus, it is not recommended to use direct message routing (<mt>=2 or 3, <bm>=2 or 3, or <ds>=1) with <mode> value 0 or 2

When +CSMS <service> is set to 0, all received SMS are automatically stored in SIM before +CMT or +CMTI URC is sent to TE whatever <mt> value.

When +CSMS <service> is set to 1, depending of it class, SMS has to be acknowledged to network thanks to +CNMA commands. Depending of <mode>, <mt> and channel status (available or reserved) URC can not or should not be sent to TE. In these cases SMS can be automatically acknowledged or rejected without waiting +CNMA command.

"BM" storage is not supported hence +CBMI is not supported.

"SR" storage is not supported by platform hence +CDSI is not supported.

+CNMI parameters are automatically saved in non-volatile memory.

+CNMA New Message Acknowledgement to ME/TA

Description	Command	Possible Response(s)

Acknowledge indication	if text mode (+CMGF=1):
	+CNMA
	
	if PDU mode (+CMGF=0):
	+CNMA[=<n>[,<length>[<CR>PDU is given<ctrl-Z/ESC>]]]
		OK
		+CME ERROR: <err>

Get supported values	+CNMA=?	if PDU mode (+CMGF=0):
		+CNMA: (list of supported <n>s)
		OK
		if text mode (+CMGF=1):
		OK
		+CME ERROR: <err>

Parameters

<n>	Description
0	Command operates similarly as defined for the text mode
1	Send RP-ACK (or buffered result code received correctly)

<n>	Description
2	Send RP-ERROR Acknowledgement TPDU not supported

Clarification

This command is allowed only if +CSMS <service> is set to 1 and is used to acknowledge SMS received from network.

Routing of SMS-DELIVER and SMS-STATUS-REPORT to ME/TA depends on both +CSMS configuration as well as <mt> and <ds> values of +CNMI.

In PDU, acknowledgement TPDU is not supported.

The following table summarizes the SMS-DELIVER notification modes according to these parameters:

+CNMI <mt>	+CSMS <service>=0	+CSMS <service>=1
0	SMS DELIVER mode = 0	SMS DELIVER mode = 0
1	SMS DELIVER mode = 0	SMS DELIVER mode = 0
2	SMS DELIVER mode = 0	SMS DELIVER mode = 1
3	SMS DELIVER mode = 0	SMS DELIVER mode = 2

When SMS Mode = 0: SMS acknowledgement and storage are managed internally by MS whatever their class (if needed they will be stored in SIM)

When SMS-DELIVER Mode = 1: SMS with no message class, class 0, class 1, class 3 are sent to ME/TA for acknowledgement (+CNMA expected), they will not be stored in ME, it's up to TE to store them. SMS class 2 & message waiting indication group (Store or Discard) are managed internally by MS (if needed they will be stored in SIM, no +CNMA expected).

When SMS-DELIVER Mode = 2: SMS class 3 are sent to ME/TA for acknowledgement (+CNMA expected), they will not be stored in ME, it's up to TE to store them. SMS with no message class, class 0, class 1, class 2 & message in waiting group are managed internally by MS (if needed they will be stored in SIM, no +CNMA expected).

Following table summarizes the STATUS-REPORT (SR) notification modes according to +CSMS and <ds> parameters:

+CNMI <ds>	+CSMS <service>=0	+CSMS <service>=1
0	STATUS REPORT mode = 0	STATUS REPORT mode = 0
1	STATUS REPORT mode = 0	STATUS REPORT mode = 1

When STATUS-REPORT Mode = 0: MS manages SR internally

When STATUS-REPORT Mode = 1: SR are sent to ME/TA for acknowledgement and storage.

Refer also to +CMT URC description for waiting message indication treatment.

+CMGL List Messages

Description	Command	Possible Response(s)

List messages with status	+CMGL[=<stat>]	if text mode (+CMGF=1), command successful:
		+CMGL: <index>,<stat>,<oa/da>,[<alpha>],[<scts>] [,<tooa/toda>,<length>]<CR><LF><data>[<CR><LF>
		+CMGL: <index>,<stat>,<da/oa>,[<alpha>],[<scts>] [,<tooa/toda>,<length>]<CR><LF><data>[...]]
		OK
		
		if PDU mode (+CMGF=0) and command successful:
		+CMGL:<index>,<stat>,[<alpha>],<length><CR><LF><pdu> [<CR><LF>+CMGL:<index>,<stat>,[<alpha>],<length><CR><LF><pdu>[...]]
		OK
		
		otherwise:
		+CMS ERROR: <err>

Get supported values	+CMGL=?	+CMGL: (list of supported <stat>s) OK +CMS ERROR: <err>

Parameters

<stat>	Description
0 "REC UNREAD"	Received unread message (i.e. new message)
1 "REC READ"	Received read message
2 "STO UNSENT"	Stored unsent message
3 "STO SENT"	Stored sent message
4 “ALL”	All messages

For all other parameters, refer to 27.005 §3.1 Parameter Definitions

Other parameters are extracted from memory storage.

Clarification

Only SMS-SUBMIT and/or SMS-DELIVER can be read.

SMS-COMMAND are not supported.

CBM are not stored in ME/TA memory. CBM are not saved in SIM.

Using the <alpha> parameter will return an empty string as this parameter is not supported.

+CMGR Read Message

Description	Command	Possible Response(s)

Read a message	+CMGR=<index>	if text mode (+CMGF=1), command successful and SMS-DELIVER:
		+CMGR: <stat>,<oa>,[<alpha>],<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data>
		OK
		
		if text mode (+CMGF=1), command successful and SMS-SUBMIT:
		+CMGR: <stat>,<da>,[<alpha>][,<toda>,<fo>,<pid>,<dcs>,[<vp>],<sca>,<tosca>,<length>]<CR><LF><data>
		OK
		
		if PDU mode (+CMGF=0) and command successful:
		+CMGR: <stat>,[<alpha>],<length><CR><LF><pdu>
		OK
		
		otherwise:
		+CMS ERROR: <err>

Test if command is supported	+CMGR=?	OK +CMS ERROR: <err>

Parameters

<index>	Description
1..255	Message location in “SM” memory.

<stat>	Description
0 "REC UNREAD"	Received unread message (i.e. new message)
1 "REC READ"	Received read message
2 "STO UNSENT"	Stored unsent message
3 "STO SENT"	Stored sent message
4 “ALL”	All messages

For all other parameters, refer to 27.005 §3.1 Parameter Definitions

Other parameters are extracted from memory storage.

Clarification

Only SMS-SUBMIT and/or SMS-DELIVER can be read.

SMS-COMMAND are not supported.

CBM are not stored in ME/TA memory. CBM are not saved in SIM.

Using the <alpha> parameter will return an empty string as this parameter is not supported.

Message Sending and Writing Commands

+CMGS Send Message

Description	Command	Possible Response(s)

Send a message	if text mode (+CMGF=1):
	+CMGS=<da>[,<toda>]<CR>
	text is entered<ctrl-Z/ESC>
	
	if PDU mode (+CMGF=0)
	+CMGS=<length><CR>PDU is given<ctrl-Z/ESC>
		if text mode (+CMGF=1) and sending successful:
		+CMGS: <mr>[,<scts>]
		OK
		
		if PDU mode (+CMGF=0) and sending successful:
		+CMGS: <mr>[,<ackpdu>]
		OK
		
		if sending fails:
		+CMS ERROR: <err>

Test if command is supported	+CMGS=?	OK +CMS ERROR: <err>

Parameters

For all other parameters, refer to +CMT URC description.

In text mode <scts> is not supported, in PDU mode <ackpdu> is not supported.

Clarification

In text mode: entered text is sent to address <da> and all current settings (refer to +CSMP and +CSCA) are used to construct the actual PDU in ME/TA.

In PDU mode: <length> must indicate the number of octets coded in the TP layer data unit to be given (i.e. SMSC address octets are excluded).

The TA sends a four character sequence <CR><LF><greater_than><space> (IRA 13, 10, 62, 32) after command line is terminated with <CR>; after that text can be entered or PDU can be given from TE to ME/TA.

The DCD signal shall be in ON state while text or PDU is entered.

The echoing of entered characters back from the TA is controlled by V.25ter echo command E.

In text mode, the entered text should be formatted as follows:

- if <dcs> (set with +CSMP) indicates that GSM 7 bit default alphabet is used and <fo> indicates that TP-User-Data-Header-Indication is not set: ME/TA converts the entered text into the GSM 7 bit default alphabet according to rules of Annex A; backspace can be used to delete last character and carriage returns

can be used (previously mentioned four character sequence shall be sent to the TE after every carriage return entered by the user);

- if <dcs> indicates that 8-bit or UCS2 data coding scheme is used or <fo> indicates that TP-User-Data-Header-Indication is set: the entered text should consist of two IRA character long hexadecimal numbers which ME/TA converts into 8-bit octet (e.g. two characters 2A (IRA 50 and 65) will be converted to an octet with integer value 42).

In PDU mode:

- The PDU shall be hexadecimal format (similarly as specified for <pdu>) and given in one line; ME/TA converts this coding into the actual octets of PDU. When the length octet of the SMSC address (given in the PDU) equals zero, the SMSC address set with command Service Centre Address +CSCA is used; in this case the SMSC Type-of-Address octet shall not be present in the PDU, i.e. TPDU starts right after SMSC length octet.

Sending can be cancelled by giving <ESC> character (IRA 27).

<ctrl-Z> (IRA 26) must be used to indicate the ending of the message body or PDU.

Text length is limited to PDU max length (164).

+CMSS Send Message from Storage

Description	Command	Possible Response(s)

Send a message from storage	+CMSS=<index>[,<da>[,<toda>]]	if text mode (+CMGF=1) and sending successful:
		+CMSS: <mr>[,<scst>]
		OK
		
		if PDU mode (+CMGF=0) and sending successful:
		+CMSS: <mr>[,<ackpdu>]
		OK
		
		if sending fails:
		+CMS ERROR: <err>

Test if command is supported	+CMSS=?	OK +CMS ERROR: <err>

Parameters

<index>	Description
1..255	Message location in “SM” memory.

In text mode <scts> is not supported, in PDU mode <ackpdu> is not supported.

For all other parameters, refer to 27.005 §3.1 Parameter Definitions

Clarification

Since SMS-STATUS-REPORTs, SMS-COMMANDs and CBM are not stored in ME/TA memory, only <index>s of SMS-SUBMITs and/or SMS-DELIVERs can be used in +CMSS.

+CMGW Write Message to Memory

Description	Command	Possible Response(s)

Write a message	if text mode (+CMGF=1):
	+CMGW[=<oa/da>[,<tooa/toda>[,<stat>]]]<CR>
	text is entered<ctrl-Z/ESC>
	
	if PDU mode (+CMGF=0):
	+CMGW=<length>[,<stat>]<CR>PDU is given<ctrl-Z/ESC>
		+CMGW: <index>
		OK
		+CMS ERROR: <err>

Test if command is supported	+CMGW=?	OK +CMS ERROR: <err>

Parameters

<index>	Description
1..255	Message location in “SM” memory.

For all other parameters, refer to 27.005 §3.1 Parameter Definitions

Clarification

Text length is limited to PDU max length (164).

+CMGD Delete Message

Description	Command	Possible Response(s)
Delete a message	+CMGD=<index>[,<delflag>]	OK +CMS ERROR: <err>
Get supported values	+CMGD=?	+CMGD: (list of supported <index>s)[,(list of supported <delflag>s)] OK +CMS ERROR: <err>

Parameters

<delflag>	Description
0 (default value)	Delete the message specified in <index>
1	Delete all read messages from preferred message storage, leaving unread messages and stored mobile originated messages (whether sent or not) untouched
2	Delete all read messages from preferred message storage and sent mobile originated messages, leaving unread messages and unsent mobile originated messages untouched
3	Delete all read messages from preferred message storage, sent and unsent mobile originated messages leaving unread messages untouched
4	Delete all messages from preferred message storage including unread messages

<index>	Description
1..255	Message location in “SM” memory.

For all other parameters, refer to 27.005 §3.1 Parameter Definitions

SMS and CBM Unsolicited Result Codes

+CMTI Received SMS indication

Description	Result code
Receive a SMS already stored	+CMTI: <mem>,<index>

Parameters

<index>	Description
1..255	Message location in “SM” memory.

<mem>	Description
“SM”	Only “SM” storage possible for SMS

+CMT Received SMS indication

Description	Result code

Receive a SMS	if text mode (+CMGF=1):
	+CMT:<oa>,[<alpha>],<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data>
	
	if PDU mode (+CMGF=0):
	+CMT: [<alpha>],<length><CR><LF><pdu>

Parameters

For all other parameters, refer to 27.005 §3.1 Parameter Definitions

Clarification

When +CSMS <service> is set to 0, all received SMS are automatically stored in SIM before +CMT is sent to TE.

When +CSMS <service> is set to 1, depending of it class, SMS has to be acknowledged to network thanks to +CNMA commands. Depending of <mode>, <mt> of CNMI or channel status (available or reserved) URC cannot or should not be sent to TE. In these cases SMS can be automatically acknowledged or rejected without waiting +CNMA command.

When a +CMT URC is sent to TE for a SMS that has NOT been acknowledged by TA, a timer is started. If timer expires (15sec) before +CNMA command is received, SMS is rejected.

When a +CMT URC is sent to TE for a SMS that has already been acknowledged by TA a timer is started. If timer expires (15sec) before +CNMA command is received, SMS is automatically saved in SIM (this is to not to lost an already acknowledged SMS for which +CNMA has not been received in case of switch off). If CNMA is received before timer expiration OK is returned, else ERROR is returned (TE knows that SMS has been stored in SIM).

Message waiting indication:

There are 3 possible cases to receive voice mail notification:

- TP-DCS method (STORE/DISCARD message coding groups in DCS)
- TP-UDH (Special SMS indication IEI in UDH of the SM)
- CPHS method (originating address decoding)

In all cases, the ME manages messages notifications internally (update of EF VMWI CPHS file, acknowledgement…)

In case of TP-DCS method, for message waiting indication group (store message), +CMTI is sent. For message waiting indication group (discard message) +CMT URC is sent but no +CNMA command is expected.

Voice mail waiting indication status are managed by *PSVMWN command.

Using the <alpha> parameter will return an empty string as this parameter is not supported.

+CBM Received CBM indication

Description	Result code

Receive a CBM	if text mode (+CMGF=1):
	+CBM: <sn>,<mid>,<dcs>,<page>,<pages><CR><LF><data>
	
	if PDU mode (+CMGF=0):
	+CBM: <length><CR><LF><pdu>

Parameters

For all other parameters, refer to 27.005 §3.1 Parameter Definitions

+CDS Received status report (SR) indication

Description	Result code

Receive a CDS	if text mode (+CMGF=1):
	+CDS: <fo>,<mr>,<ra>,<tora>,<scts>,<dt>,<st>
	
	if PDU mode (+CMGF=0):
	+CDS: <length><CR><LF><pdu>

Parameters

For all other parameters, refer to 27.005 §3.1 Parameter Definitions

Clarification

When +CSMS <service> is set to 0, all received SR are automatically acknowledged before +CDS is sent to TE.

When +CSMS <service> is set to 1, SR has to be acknowledged to network thanks to +CNMA commands. Depending of <mode>, <mt> and channel status (available or reserved) URC can not or should not be sent to TE. In these cases SR can be automatically acknowledged or rejected without waiting +CNMA command.

+CMS ERROR Message Service Failure Result Code

Value	Description
0...127	3GPP TS 24.011 [6] clause E.2 values

Value	Description
128...255	3GPP TS 23.040 [3] clause 9.2.3.22 values
300	ME failure
301	SMS service of ME reserved
302	Operation not allowed
303	Operation not supported
304	Invalid PDU mode parameter
305	Invalid text mode parameter
310	(U)SIM not inserted
311	(U)SIM PIN required
312	PH-(U)SIM PIN required
313	(U)SIM failure
314	(U)SIM busy
315	(U)SIM wrong
316	(U)SIM PUK required
317	(U)SIM PIN2 required
318	(U)SIM PUK2 required
320	Memory failure
321	Invalid memory index
322	Memory full
330	SMSC address unknown
331	No network service
332	Network timeout
340	No +CNMA acknowledgement expected
500	Unknown error

3. 3GPP TS 27.007 Commands

General Commands

+CGMI Request Manufacturer identification

Description	Command	Possible Response(s)
Read manufacturer Id	+CGMI	<manufacturer> OK +CME ERROR: <err>
Test if command is supported	+CGMI=?	OK

Parameters

<manufacturer>	Description
String type	Manufacturer identification (WAVECOM MODEM)

+CGMM Request Model Identification

Description	Command	Possible Response(s)
Read model	+CGMM	<model> OK +CME ERROR: <err>
Test if command is supported	+CGMM=?	OK

Parameters

<model>	Description
String type	Model identification (WISMO218)

+CGMR Request Revision Identification

Description	Command	Possible Response(s)
Read revision	+CGMR	<revision> OK +CME ERROR: <err>
Test if command is supported	+CGMR=?	OK

Parameters

<revision>	Description
String type	Revision identification (example: B02d00gg.WISMO218 250509)

+CGSN Request product serial number identification

Description	Command	Possible Response(s)
Read SN	+CGSN	<sn> OK +CME ERROR: <err>
Test if command is supported	+CGSN=?	OK

Parameters

<sn>	Description
String type	International mobile equipment identity (IMEI) 15 digits

+CSCS Select TE character set

Description	Command	Possible Response(s)
Set charset	+CSCS[=<chset>]	OK +CME ERROR: <err>
Read current charset	+CSCS?	+CSCS: <chset> OK +CME ERROR: <err>
Get supported values	+CSCS=?	+CSCS: (list of supported <chset>s) OK +CME ERROR: <err>

Parameters

<chset>	Description
“GSM”	GSM 7 bit default alphabet (3GPP TS 23.038)
“UCS2”	16-bit universal multiple-octet coded character set (ISO/IEC10646); UCS2 character strings are converted to hexadecimal numbers from 0000 to FFFF; e.g. "004100620063" equals three 16-bit characters with decimal values 65, 98 and 99
“IRA” (default value)	International reference alphabet (ITU-T T.50)

Clarification

The <chset> parameter is automatically saved in non-volatile memory and restored to default value by AT&F command.

+CIMI Request international mobile subscriber identity

Description	Command	Possible Response(s)
Read IMSI	+CIMI	<IMSI> OK +CME ERROR: <err>
Test if command is supported	+CIMI=?	OK +CME ERROR: <err>

Parameters

<IMSI>	Description
String type (without double quotes)	International Mobile Subscriber Identity (IMSI)

+CMUX Multiplexing mode

Description	Command	Possible Response(s)
Activate MUX protocol	+CMUX=<mode>[,<subset>[,<port_speed>[,<N1>[,<T1> [,<N2>[,<T2>[,<T3> [,<k>]]]]]]]	OK +CME ERROR: <err>
Read current settings	+CMUX?	+CMUX: <mode>,[<subset>],<port_speed>,<N1>,<T1>, <N2>,<T2>,<T3>[,<k>] OK

Description	Command	Possible Response(s)
Get supported values	+CMUX=?	+CMUX: (list of supported <mode>s),(list of supported <subset>s),(list of supported <port_speed>s),(list of supported <N1>s),(list of supported <T1>s),(list of supported <N2>s),(list of supported <T2>s),(list of supported <T3>s),(list of supported <k>s) OK

Parameters

<mode>	Description
0	Basic option
1	Advanced option

<subset>	Description
0 (default)	UIH frames used only
1	UI frames used only

<port_speed>	Description
1	9 600 bits/s
2	19 200 bits/s
3	38 400 bits/s
4	57 600 bits/s
5	115 200 bits/s
6	230 400 bits/s
7	460 800 bits/s
8	921 600 bits/s

<N1>	Description
1- 32768	Maximum frame size Default: 31 (64 if Advanced option is used)

<T1>	Description
1-255	Acknowledgement timer in units of ten milliseconds Default: 10 (100 ms)

<N2>	Description
0-100	Maximum number of re-transmissions Default: 3

<T2>	Description
2-255	Response timer for the multiplexer control channel in units of ten milliseconds Default: 30

<T3>	Description
1-255	Wake up response timer in seconds Default: 10

<k>	Description
1-7	window size, for Advanced operation with Error Recovery options Default: 2

Clarification

Value 2 for subset parameter is not supported because CMUX is not running in error recovery mode.

Refer also to 27.010 for more information on parameters values.

+CMUX parameters are automatically stored in non-volatile memory:

Parameter name	Default value
<mode>	0x00
<subset>	0x00
<port_speed>	0x05
<N1>	0x1F
<T1>	0x0A

Parameter name	Default value
<N2>	0x03
<T2>	0x1E
<T3>	0x0A
<k>	0x02

Default values are used when +CMUX parameters are left out.

+CMUX parameters are restored to default values by AT&F command.

Call Control Commands

+CSTA Select type of address

Description	Command	Possible Response(s)
Select type of address	+CSTA=[<type>]	OK +CME ERROR: <err>
Get current type	+CSTA?	+CSTA: <type> OK +CME ERROR: <err>
Get supported types	+CSTA=?	+CSTA: (list of supported <type>s) OK +CME ERROR: <err>

Parameters

<type>	Description
129 (default)	National type of address
145	International type of address
Omitted	Use previous value

Clarification

The <type> parameter is automatically saved into non-volatile memory and restored to the default value by AT&F command.

+CMOD Call mode

Description	Command	Possible Response(s)
Select call mode	+CMOD=[<mode>]	OK +CME ERROR: <err>
Get current type	+CMOD?	+CMOD: <mode> OK
Get supported types	+CMOD=?	+CMOD: (list of supported <mode>s) OK

Parameters

<mode>	Description
0	Single mode

Clarification

This command has no effect. It is for compatibility only.

+CHUP Hang-up call

Description	Command	Possible Response(s)
Hang up calls	+CHUP	OK +CME ERROR: <err>
Test if command is supported	+CHUP=?	OK +CME ERROR: <err>

Clarification

+CHUP command gives an assured procedure to disconnect the call.

Refer to H command description.

Since only single mode is supported, the execution of the command always disconnects active call.

+CBST Select bearer service type

Description	Command	Possible Response(s)
Select bearer	+CBST=[<speed>[,<name>[,<ce>]]]	OK +CME ERROR: <err>

Description	Command	Possible Response(s)
Get current bearer	+CBST?	+CBST: <speed>,<name>,<ce> OK
Get supported types	+CBST=?	+CBST: (list of supported <speed>s),(list of supported <name>s),(list of supported <ce>s)

Parameters

<speed>	Description
0	Autobauding (automatic selection of the speed; this setting is possible in case of 3.1 kHz modem and non-transparent service)
7 (default value)	9600 bps (V.32)
71	9600 bps (V.110 or X.31 flag stuffing)

<name>	Description
0 (default value)	Data circuit asynchronous (UDI or 3.1 kHz modem)
1	Data circuit synchronous (UDI or 3.1 kHz modem) (Not supported)

<ce>	Description
0	Transparent (Not supported)
1 (default value)	Non-transparent

Clarification

+CBST parameters are saved into non-volatile memory by AT&W command. Default values are not restored by AT&F command.

+CRLP Radio link protocol

Description	Command	Possible Response(s)
Select protocol	+CRLP=[<iws>[,<mws>[,<T1>[,<N2>[,<ver>[,<T4>]]]]]]	OK +CME ERROR: <err>
Get current RLP	+CRLP?	+CRLP: <iws>,<mws>,<T1>,<N2>[,<ver1>[,<T4>]] OK

Description	Command	Possible Response(s)
Get supported types	+CRLP=?	+CRLP: (list of supported <iws>s),(list of supported <mws>s), (list of supported <T1>s),(list of supported <N2>s)[,<ver1> [,(list of supported <T4>s)]] OK

Parameters

<iws>	Description
0..61	IWF to MS window size

<mws>	Description
0..61	MS to IWF window size

<T1>	Description
44..255	Acknowledgement timer T1,

<N2>	Description
1..255	Retransmission attempts N2

<ver1>	Description
0	RLP version

<T4>	Description
7	Re-sequencing period T4 in integer format

+CR Service reporting

Description	Command	Possible Response(s)
Select service reporting mode	+CR=[<mode>]	OK +CME ERROR: <err>

Description	Command	Possible Response(s)
Get current mode	+CR?	+CR: <mode> OK
Get supported modes	+CR=?	+CR: (list of supported <mode>s) OK

Parameters

<mode>	Description
0 (default value)	Disable reporting
1	Enable reporting
Omitted	Use previous value

Clarification

The <mode> parameter is automatically saved into non-volatile memory and restored to default value by AT&F command.

+CEER Extended error report

Description	Command	Possible Response(s)
Get last error report	+CEER	+CEER: <report> OK
Test if command is supported	+CEER=?	OK

Parameters

<report>	Description
String type	String “Cause Select:<cs> Cause:<c>” is returned <cs> and <c> are numbers representing the CauseSelect and Cause

CauseSelect <cs>	Cause <c>
0 (No cause)	0 (No cause)
16 (Service provider)	0 (Unknown)
	1 (Not Allowed)

CauseSelect <cs>	Cause <c>
	2 (No cause)
	6 (Wrong parameter)
	9 (Network access not allowed)
	20 (All call instances are used)
	21 (ACM over ACM Max)
	22 (Invalid AOC element)
	23 (SIM increase not allowed)
	24 (Switch off)
	25 (Unknown call id)
	28 (Barred)
65 (Local cause)	1 (State error)
	2 (No call entity)
	3 (Wrong TI)
	6 (DTMF buffer overflow)
	7 (Call disconnected)
	17 (No cell available)
	32 (Local rejection)
	33 (PLMN not allowed)
	34 (Emergency call not possible)
	35 (Authentication rejected)
	36 (Network rejection)
	37 (LA not allowed)
	38 (Local timeout)
	39 (Server congestion)
	40 (Local data rejection)
	48 (Failed replace PDP context)
66 (MM network cause)	See [24.008]

CauseSelect <cs>	Cause <c>
67 (CC network cause)	See [24.008]
69 (RP cause)	See [24.008]
71 (SIM cause)	0 (Unknown problem)
	1 (Memory problem)
	2 (File Id not found)
	6 (Increase problem)
	7 (Technical problem)
	11 (Command not allowed)
	15 (SIM card out)
73 (SM cause)	See [24.008]

+CRC Cellular result codes

Description	Command	Possible Response(s)
Select service CR mode	+CRC=[<mode>]	OK +CME ERROR: <err>
Get current mode	+CRC?	+CRC: <mode> OK
Get supported modes	+CRC=?	+CRC: (list of supported <mode>s) OK

Parameters

<mode>	Description
0 (default)	Disables extended format
1	Enables extended format
Omitted	Use previous value

Clarification

+CRC parameter is automatically saved into non-volatile memory.

The <mode> parameter is restored to default value by AT&F command.

+CVHU Voice Hang-up Control

Description	Command	Possible Response(s)
Select service voice hang up mode	+CVHU=[<mode>]	OK +CME ERROR: <err>
Get current mode	+CVHU?	+CVHU: <mode> +CME ERROR: <err>
Get supported modes	+CVHU=?	+CVHU: (list of supported <mode>s) +CME ERROR: <err>

Parameters

<mode>	Description
0 (default value)	"Drop DTR" ignored but OK response given. ATH disconnects.
1	"Drop DTR" and ATH ignored but OK response given
2	"Drop DTR" behavior according to &D setting. ATH disconnects
Omitted	Use previous value

Clarification

If DTR signal is inactive (if DTR is not a pulse), then “Drop DTR” does not respond “OK”.

The <mode> parameter is restored to default value by AT&F command.

Call Control Result Code

+CR Service reporting

Description	Result code
+CR notification sent during data call connection	+CR: <serv>

Parameters

<serv>	Description
ASYNC	Asynchronous transparent
SYNC	Synchronous transparent
REL ASYNC	Asynchronous non-transparent

<serv>	Description
REL SYNC	Synchronous non-transparent
GPRS	GPRS

+CRING Ring indication

Description	Result code
Extended format for incoming call notification	+CRING: <type>

Parameters

<type>	Description
ASYNC	Asynchronous transparent
SYNC	Synchronous transparent
REL ASYNC	Asynchronous non-transparent
REL SYNC	Synchronous non-transparent
FAX	Fax
VOICE	Voice call
VOICE AUX	Proprietary value for ALS (CPHS Alternate line service) Used in case of incoming on line 2 Refer to *PSALS

Clarification

Note: If alternate line service is activated, <type> = “VOICE” if speech call is on line 1 and “VOICE AUX” if call is on line 2.

Network Service Related Commands

+CNUM Subscriber number

Description	Command	Possible Response(s)
Get MSISDNs	+CNUM	+CNUM: [<alpha1>],<number1>,<type1>[,<speed>,<service>[,<itc>]] [<CR><LF>+CNUM: [<alpha2>],<number2>,<type2>[,<speed>,<service> [,<itc>]] [...]] OK +CME ERROR: <err>
Test if command is supported	+CNUM =?	+CNUM: (0-1),(list of supported <typex>s) OK +CME ERROR: <err>

Parameters

<alphax>	Description
String type	Alphanumeric string associated with <numberx>; used character set should be the one selected with +CSCS (Not supported)

<numberx>	Description
String type	Phone number

<typex>	Description
Integer type	Type of address

<speed>	Description
Integer type	Same as +CBST

<service>	Description
0	Asynchronous modem
1	Synchronous modem
2	PAD Access (asynchronous)
3	Packet Access (synchronous)

<service>	Description
4	Voice
5	Fax

<itc>	Description
0	3,1 kHz
1	UDI

Clarification

Using the <alphax> parameter will return an empty string as this parameter is not supported.

+CREG Network registration

Description	Command	Possible Response(s)
Control +CREG notification	+CREG=[<n>]	OK +CME ERROR: <err>
Get current registration status	+CREG?	+CREG: <n>,<stat>[,<lac>,<ci>] OK
Get supported values	+CREG=?	+CREG: (list of supported <n>s) OK

Parameters

<n>	Description
0 (default)	Disable network registration unsolicited result code
1	Enable network registration and location information unsolicited result code +CREG: <stat>
2	Enable network registration and location information unsolicited result code +CREG: <stat>[,<lac>,<ci>]
Omitted	Use previous value

<stat>	Description
0	Not registered, MT is not currently searching a new operator to register to
1	Registered, home network
2	Not registered, but MT is currently searching a new operator to register to

<stat>	Description
3	Registration denied
4	Unknown
5	Registered, roaming

<lac>	Description
String type	Two bytes location area code in hexadecimal format (e.g. "00C3" equals 195 in decimal)

<ci>	Description
String type	Two bytes cell ID in hexadecimal format

Clarification

+CREG parameter is automatically saved into non-volatile memory.

The <n> parameter is restored to default value by AT&F command.

Using the <alphax> parameter will return an empty string as this parameter is not supported.

+COPS Operator Selection

Description	Command	Possible Response(s)
Select operator	+COPS=[<mode>[,<format>[,<oper>[,< AcT>]]]]	OK +CME ERROR: <err>
Get current mode and operator	+COPS?	+COPS: <mode>[,<format>, <oper>[,< AcT>]] OK +CME ERROR: <err>
Get supported values	+COPS=?	+COPS: [list of supported (<stat>,long alphanumeric <oper>,short alphanumeric <oper>,numeric <oper>[,< AcT>])s][,,(list of supported <mode>s),(list of supported <format>s)] OK +CME ERROR: <err>

Parameters

<mode>	Description
0 (default)	Automatic (<oper> field is ignored)
1	Manual (<oper> field shall be present, and <AcT> optionally)
3	Set only <format> (for read command +COPS?), do not attempt registration/deregistration (<oper> and < AcT> fields are ignored); this value is not applicable in read command response
4	Manual/automatic (<oper> field shall be present); if manual selection fails, automatic mode (<mode>=0) is entered

<format>	Description
0 (default)	Long format alphanumeric <oper>
2	Numeric <oper>

<oper>	Description
String type	Operator name (refer to [27.007])

<AcT>	Description
0	GERAN
2	UTRAN

<stat>	Description
0	Unknown
1	Available
3	Current
4	Forbidden

Clarification

When Manual/automatic operator selection is requested (<mode>=4), +COPS will return <mode>=0 or <mode>=1 depending which registration mode was successful (<mode>=4 will not be returned)

If set command is aborted, an abort of the registration ongoing is requested.

If test command is aborted, get available PLMN procedure is aborted, a partial list of PLMN is returned.

+CLCK Facility lock

Description	Command	Possible Response(s)
Execute facility operation	+CLCK=<fac>,<mode>[,<passwd>[,<class>]]	when <mode>=2 and command successful: +CLCK: <status>[,<class1>[<CR><LF>+CLCK: <status>,<class2>[…]] OK +CME ERROR: <err>
Get supported values	+CLCK=?	+CLCK: (list of supported <fac>s) OK +CME ERROR: <err>

Parameters

<fac>	Description
SC	SIM (lock SIM/UICC card) (SIM/UICC asks password in MT power-up and when this lock command is issued) Correspond to PIN1 code
AO	BAOC (Barr All Outgoing Calls)
OI	BOIC (Barr Outgoing International Calls)
OX	BOIC-exHC (Barr Outgoing International Calls except to Home Country)
AI	BAIC (Barr All Incoming Calls)
IR	BIC-Roam (Barr Incoming Calls when Roaming outside the home country)
AB	All Barring services
FD	SIM card or active application in the UICC (GSM or USIM) fixed dialling memory feature (if PIN2 authentication has not been done during the current session, PIN2 is required as <passwd>)
PN	Network Personalization Correspond to NCK code
PU	Network sUbset Personalization Correspond to NSCK code
PP	Service Provider Personalization Correspond to SPCK code
AC	All inComing barring services
AG	All outGoing barring services

<mode>	Description
0	Unlock
1	Lock
2	Query status

<passwd>	Description
String type	Shall be the same as password specified for the facility from the MT user interface or with command Change Password +CPWD

<class>	Description
1	Voice (telephony)
2	Data (refers to all bearer services; with <mode>=2 this may refer only to some bearer service if TA does not support values 16, 32, 64 and 128)
4	Fax (facsimile services)
7	All

<status>	Description
0	Not active
1	Active

+CPWD Change password

Description	Command	Possible Response(s)
Set new password	+CPWD=<fac>,<oldpwd>,<newpwd>	OK +CME ERROR: <err>
Get supported values	+CPWD =?	+CPWD: list of supported (<fac>,<pwdlength>)s OK +CME ERROR: <err>

Parameters

<fac>	Description
P2	SIM PIN2
AO or OI or OX or AI or IR or AB or SC	Refer Facility Lock +CLCK for description

<oldpwd> <newpd>	Description
String type	<oldpwd> shall be the same as password specified for the facility from the MT user interface or with command Change Password +CPWD and <newpwd> is the new password; maximum length of password can be determined with <pwdlength>

<pwdlength>	Description
Integer type	Maximum length of the password for the facility

+CLIP Calling line identification presentation

Description	Command	Possible Response(s)
Control +CLIP notification	+CLIP=[<n>]	OK +CME ERROR: <err>
Get status of CLIP	+CLIP?	+CLIP: <n>,<m> OK +CME ERROR: <err>
Get supported values	+CLIP=?	+CLIP: (list of supported <n>s) OK +CME ERROR: <err>

Parameters

<n>	Description
0 (default)	Disable +CLIP notification
1	Enable +CLIP notification

<m>	Description
0	CLIP not provisioned
1	CLIP provisioned
2	Unknown (e.g. no network, etc.)

Clarification

+CLIP parameter is automatically saved in non-volatile memory.

The <n> parameter is restored to default value by AT&F command.

+CLIR Calling line identification restriction

Description	Command	Possible Response(s)
Control +CLIR	+CLIR=[<n>]	OK +CME ERROR: <err>
Get status of CLIR	+CLIR?	+CLIR: <n>,<m> OK +CME ERROR: <err>
Get supported values	+CLIR=?	+CLIR: (list of supported <n>s) OK +CME ERROR: <err>

Parameters

<n>	Description
0 (default value)	Presentation indicator is used according to the subscription of the CLIR service
1	CLIR invocation
2	CLIR suppression

<m>	Description
0	CLIR not provisioned
1	CLIR provisioned in permanent mode
2	Unknown (e.g. no network, etc.)
3	CLIR temporary mode presentation restricted

<m>	Description
4	CLIR temporary mode presentation allowed

Clarification

The <n> parameter is automatically saved into non-volatile memory and restored to default value by AT&F command.

+COLP Connected line identification presentation

Description	Command	Possible Response(s)
Control +COLP notification	+COLP=[<n>]	OK +CME ERROR: <err>
Get status of COLP	+COLP?	+COLP: <n>,<m> OK +CME ERROR: <err>
Get supported values	+COLP=?	+COLP: (list of supported <n>s) OK +CME ERROR: <err>

Parameters

<n>	Description
0	Disable +COLP notification
1	Enable +COLP notification

<m>	Description
0	COLP not provisioned
1	COLP provisioned
2	Unknown (e.g. no network, etc.)

+CCFC Call forwarding number and conditions

Description	Command	Possible Response(s)
Control +COLP notification	+CCFC=<reason>,<mode>[,<number>[,<type>[,<class>[,<subaddr>[,<satype>[,<time>]]]]]]	when <mode>=2 and command successful: +CCFC: <status>,<class1>[,<number>,<type>[,<subaddr>,<satype>[,<time>]]] [<CR><LF>+CCFC: <status>,<class2>[,<number>,<type>[,<subaddr>,<satype>[,<time>]]][…] OK +CME ERROR: <err>
Get supported values	+CCFC=?	+CCFC: (list of supported <reason>s) OK +CME ERROR: <err>

Parameters

<reason>	Description
0	Unconditional
1	Mobile busy
2	No reply
3	Not reachable
4	All call forwarding
5	All conditional call forwarding

<mode>	Description
0	Disable
1	Enable
2	Query status
3	Registration
4	Erasure

<number>	Description
String type	Phone number of forwarding address in format specified by <type>

<type>	Description
Integer type	Type of address

<subaddr>	Description
String type	Subaddress of format specified by <satype>

<satype>	Description
Integer type	Type of subaddress

<class>	Description
1	Voice (telephony)
2	Data (refers to all bearer services; with <mode>=2 this may refer only to some bearer service if TA does not support values 16, 32, 64 and 128)
4	Fax (facsimile services)
7 (default)	All

<time>	Description
1..30	When "no reply" is enabled or queried, this gives the time in seconds to wait before call is forwarded Default value: 20

<status>	Description
0	Not active
1	Active

+CCWA Call waiting

Description	Command	Possible Response(s)
Control call waiting	+CCWA=[<n>[,<mode>[,<class>]]]	when <mode>=2 and command successful: +CCWA: <status>,<class1>[<CR><LF>+CCWA: <status>,<class2> […]] OK +CME ERROR: <err>

Description	Command	Possible Response(s)
Get current mode	+CCWA?	+CCWA: <n> OK +CME ERROR: <err>
Get supported values	+CCWA=?	+CCWA: (list of supported <reason>s) OK +CME ERROR: <err>

Parameters

<n>	Description
0	Disable presentation of +CCWA
1	Enable presentation of +CCWA

<mode>	Description
0	Disable
1	Enable
2	Query status

<class>	Description
1	Voice (telephony)
2	Data (refers to all bearer services; with <mode>=2 this may refer only to some bearer service if TA does not support values 16, 32, 64 and 128)
4	Fax (facsimile services)
7 (default)	All

<status>	Description
0	Not active
1	Active

+CHLD Call related supplementary services

Description	Command	Possible Response(s)
Control call related services	+CHLD=[<n>]	OK +CME ERROR: <err>
Get supported values	+CHLD=?	+CHLD: (list of supported <n>s) OK +CME ERROR: <err>

Parameters

<n>	Description
0	Releases all held calls or sets User Determined User Busy (UDUB) for a waiting call.
1	Releases all active calls (if any exist) and accepts the other (held or waiting) call.
1x	Releases a specific active call x
2	Places all active calls (if any exist) on hold and accepts the other (held or waiting) call.
2x	Places all active calls on hold except call X with which communication shall be supported.
3	Adds a held call to the conversation.
4	Connects the two calls and disconnects the subscriber from both calls (ECT)

+CTFR Call deflection

Description	Command	Possible Response(s)
Deflect a MT call	+CTFR=<number>[,<type>[,<subaddr>[,<satype>]]]	OK +CME ERROR: <err>
Test if command is supported	+CTFR=?	OK +CME ERROR: <err>

Parameters

<number>	Description
String type	Phone number

<type>	Description
Integer type	Type of address

<subaddr>	Description
String type	Subaddress of format specified by <satype>

<satype>	Description
Integer type	Type of subaddress

+CUSD Unstructured supplementary service data

Description	Command	Possible Response(s)
Control USSD	+CUSD=[<n>[,<str>[,<dcs>]]]	OK +CME ERROR: <err>
Get current mode	+CUSD?	+CUSD: <n> OK +CME ERROR: <err>
Get supported values	+CUSD=?	+CUSD: (list of supported <n>s) OK +CME ERROR: <err>

Parameters

<n>	Description
0	Disable the result code presentation to the TE
1	Enable the result code presentation to the TE
2	Cancel session (not applicable to read command response)

<str>	Description
String type	USSD-string

<dcs>	Description
Integer type	Cell Broadcast Data Coding Scheme Default value: 0

Clarification

When TE sends an USSD to the network, the OK result code is sent before the response of the network. When network answers, the response will be sent as an URC (as if it was a network initiated operation, in case of error +CUSD: 4 will be sent).

This allows the link not to be blocked for a long time (the network can take a long time to answer a USSD request initiated by the TE).

The USSD session can be aborted using command at+cusd=2.

+CAOC Advice of Charge

Description	Command	Possible Response(s)
Control AOC notification	+CAOC[=<mode>]	If <mode>=0: +CAOC: <ccm> OK +CME ERROR: <err>
Get current mode	+CAOC?	+CAOC: <mode> OK +CME ERROR: <err>
Get supported values	+CAOC=?	+CAOC: (list of supported <mode>s) OK +CME ERROR: <err>

Parameters

<mode>	Description
0	Query CCM value
1	Deactivate the unsolicited reporting of CCM value
2	Activate the unsolicited reporting of CCM value

<ccm>	Description
String type	Three bytes of the current call meter value in hexadecimal format (e.g. "00001E" indicates decimal value 30); value is in home units and bytes are similarly coded as ACMmax value in the SIM card or in the active application in the UICC (GSM or USIM)

+CSSN Supplementary service notifications

Description	Command	Possible Response(s)
SS notification control	+CSSN=[<n>[,<m>]]	OK +CME ERROR: <err>
Get current mode	+CSSN?	+CSSN: <n>,<m> OK
Get supported values	+CSSN=?	+CSSN: (list of supported <n>s),(list of supported <m>s) OK

Parameters

<n>	Description
0 (default)	Disable presentation of +CSSI
1	Enable presentation of +CSSI

<m>	Description
0 (default)	Disable presentation of +CSSU
1	Enable presentation of +CSSU

Clarification

+CSSN parameters are automatically saved into non-volatile memory.

+CLCC List current calls

Description	Command	Possible Response(s)
SS notification control	+CLCC	[+CLCC: <id1>,<dir>,<stat>,<mode>,<mpty>[,<number>,<type>[,<alpha>]][<CR><LF>+CLCC: <id2>,<dir>,<stat>,<mode>,<mpty>[,<number>,<type>[,<alpha>]][...]]] OK +CME ERROR: <err>
Test if command is supported	+CLCC=?	OK +CME ERROR: <err>

Parameters

<idx>	Description
1..7	Call identification number This number can be used in +CHLD command operations

<dir>	Description
0	Mobile originated (MO) call
1	Mobile terminated (MT) call

<stat>	Description
0	Active
1	Held
2	Dialing (MO call)
3	Alerting (MO call)
4	Incoming (MT call)
5	Waiting (MT call)

<mode>	Description
0	Voice
1	Data
2	Fax

<mpty>	Description
0	Call is not one of multiparty (conference) call parties
1	Call is one of multiparty (conference) call parties

<number>	Description
String type	Phone number

<type>	Description
Integer type	Type of address

<Alpha>	Description
String type	Alphanumeric representation of <number> corresponding to the entry found in phonebook; used character set should be the one selected with +CSCS (Not supported)

Clarification

Using the <alpha> parameter will return an empty string as this parameter is not supported.

+CPOL Preferred PLMN list

Description	Command	Possible Response(s)
Write an entry in list of preferred PLMNs	+CPOL=[<index>][,<format>[,<oper>[,<GSM_AcT>,<GSM_Compact_AcT>,<UTRAN_AcT>]]]	OK +CME ERROR: <err>
List all entries	+CPOL?	+CPOL: <index1>,<format>,<oper1>[,<GSM_AcT1>,<GSM_Compact_AcT1>,<UTRAN_AcT1>][<CR><LF>+CPOL: <index2>,<format>,<oper2>[,<GSM_AcT2>,<GSM_Compact_AcT2>,<UTRAN_AcT2>][...]] OK +CME ERROR: <err>
Get supported values	+CPOL=?	+CPOL: (list of supported <index>s),(list of supported <format>s) OK +CME ERROR: <err>

Parameters

<index>	Description
Integer type	The order number of operator in the SIM/USIM preferred operator list

<format>	Description
0	Long format alphanumeric <oper>
1	Short format alphanumeric <oper>
2	Numeric <oper>

<opern>	Description
String type	Operator name (refer to [27.007])

<GSM_AcTn>	Description
0	Access technology not selected
1	Access technology selected

<GSM_Compact_AcTn>	Description
0	Access technology not selected
1	Access technology selected

<UTRAN_AcTn>	Description
0	Access technology not selected
1	Access technology selected

Clarification

Note: <GSM_AcT>, <GSM_Compact_AcT> and <UTRAN_AcT> appears in 27.007 Release 5.

+CPLS Selection of preferred PLMN list

Description	Command	Possible Response(s)
Select the list of preferred PLMN for CPOL	+CPLS=<list>	OK +CME ERROR: <err>
Get current list	+CPLS?	+CPLS: <list> OK +CME ERROR: <err>
Get supported values	+CPLS=?	+CPLS: (list of supported <list>s) OK +CME ERROR: <err>

Parameters

<list>	Description
0	User controlled PLMN selector with Access Technology EFPLMNwAcT, if not found in the SIM/UICC then PLMN preferred list EFPLMNsel (this file is only available in SIM card or GSM application selected in UICC)
1	Operator controlled PLMN selector with Access Technology EFOPLMNwAcT

Clarification

Note: This command appears in 27.007 Release 5, but SIM files EFPLMNwAcT, EFOPLMNwAcT exists in Release 99.
The <list> parameter is automatically saved into non-volatile memory.

+COPN Read operator names

Description	Command	Possible Response(s)
Get list of operator name	+COPN	+COPN: <numeric1>,<alpha1>[<CR><LF>+COPN: <numeric2>,<alpha2>[...]] OK +CME ERROR: <err>
Test if command is supported	+COPN=?	OK +CME ERROR: <err>

Parameters

<numericn>	Description
String type	Operator in numeric format (see +COPS)

<alphan>	Description
String type	Operator in long alphanumeric format (see +COPS)

Network Service Related Result Codes

+CREG Network registration

Description	Result code
Network registration status change event	+CREG: <stat>[,<lac>,<ci>]

Parameters

Refer to +CREG command description.

+CLIP Calling Line Identification Presentation

Description	Result code
Calling Line Identification Presentation	+CLIP: <number>,<type>[,<subaddr>,<satype>[,[<alpha>][,<CLI validity>]]]

Parameters

<number>	Description
String type	Phone number

<type>	Description
Integer type	Type of address

<subaddr>	Description
String type	Subaddress of format specified by <satype>

<satype>	Description
Integer type	Type of subaddress

<alpha>	Description
String type	Alphanumeric representation of <number> corresponding to the entry found in phonebook; used character set should be the one selected with +CSCS (Not supported)

<CLI validity>	Description
0	CLI valid
1	CLI has been withheld by the originator
2	CLI is not available due to interworking problems or limitations of originating network

Clarification

Using the <alpha> parameter will return an empty string as this parameter is not supported.

+COLP Connected line identification presentation

Description	Result code
Connected Line Identification Presentation	+COLP: <number>,<type>[,<subaddr>,<satype>[,<alpha>]]

Parameters

<number>	Description
String type	Phone number

<type>	Description
Integer type	Type of address

<subaddr>	Description
String type	Subaddress of format specified by <satype>

<satype>	Description
Integer type	Type of subaddress

<alpha>	Description
String type	Alphanumeric representation of <number> corresponding to the entry found in phonebook; used character set should be the one selected with +CSCS (Not supported)

Clarification

Using the <alpha> parameter will return an empty string as this parameter is not supported.

+CCWA Calling Line Identification Presentation

Description	Result code
Call waiting notification	+CCWA: <number>,<type>,<class>[,<alpha>][,<CLI validity>[,<subaddr>,<satype>]]

Parameters

<number>	Description
String type	Phone number

<type>	Description
Integer type	Type of address

<subaddr>	Description
String type	Subaddress of format specified by <satype>

<satype>	Description
Integer type	Type of subaddress

<alpha>	Description
String type	Alphanumeric representation of <number> corresponding to the entry found in phonebook; used character set should be the one selected with +CSCS (Not supported)

<class>	Description
1	Voice (telephony)
2	Data (refers to all bearer services; with <mode>=2 this may refer only to some bearer service if TA does not support values 16, 32, 64 and 128)
4	Fax (facsimile services)
7 (default)	All

<CLI validity>	Description
0	CLI valid
1	CLI has been withheld by the originator
2	CLI is not available due to interworking problems or limitations of originating network

Clarification

Using the <alpha> parameter will return an empty string as this parameter is not supported.

+CUSD Unstructured supplementary service data

Description	Result code
USSD response from the network, or network initiated operation	+CUSD: <m>[,<str>,<dcs>]

Parameters

<n>	Description
0	No further user action required (network initiated USSD Notify, or no further information needed after mobile initiated operation)
1	Further user action required (network initiated USSD Request, or further information needed after mobile initiated operation)
2	USSD terminated by network
4	Operation not supported
5	Network time out

<str>	Description
String type	USSD-string

<dcs>	Description
Integer type	Cell Broadcast Data Coding Scheme Default value: 0

Clarification

Refer to +CUSD command description.

+CCCM Current Call Meter

Description	Result code
CCM value	+CCCM: <ccm>

Parameters

<ccm>	Description
String type	Three bytes of the current call meter value in hexadecimal format (e.g. "00001E" indicates decimal value 30); value is in home units and bytes are similarly coded as ACMmax value in the SIM card or in the active application in the UICC (GSM or USIM)

Clarification

This unsolicited result code is sent whenever the CCM value changes, but not more than once every 10s. This URC is activated when CAOC is in mode 2.

+CSSI Supplementary service notification

Description	Result code
SS notification for MO call	+CSSI: <code1>

Parameters

<code1>	Description
0	Unconditional call forwarding is active
1	Some of the conditional call forwardings are active
2	Call has been forwarded
3	Call is waiting
5	Outgoing calls are barred
6	Incoming calls are barred
7	CLIR suppression rejected
8	Call has been deflected

+CSSU Supplementary service notification

Description	Result code
SS notification	+CSSU: <code2>

Parameters

<code2>	Description
0	This is a forwarded call (MT call setup)
2	Call has been put on hold (during a voice call)
3	Call has been retrieved (during a voice call)
4	Multiparty call entered (during a voice call)
5	Call on hold has been released (this is not a SS notification) (during a voice call)

<code2>	Description
7	Call is being connected (alerting) with the remote party in alerting state in explicit call transfer operation (during a voice call)
8	Call has been connected with the other remote party in explicit call transfer operation (during a voice call or MT call setup)
9	This is a deflected call (MT call setup)

Control and Status Commands

+CPAS Phone activity status

Description	Command	Possible Response(s)
Get activity status	+CPAS	+CPAS: <pas> OK +CME ERROR: <err>
Get supported values	+CPAS=?	+CPAS: (list of supported <pas>s) OK +CME ERROR: <err>

Parameters

<pas>	Description
0	Ready (MT allows commands from TA/TE)
2	Unknown (MT is not guaranteed to respond to instructions)
3	Ringing (MT is ready for commands from TA/TE, but the ringer is active)
4	Call in progress (MT is ready for commands from TA/TE, but a call is in progress)

+CFUN Set phone functionality

Description	Command	Possible Reponse(s)
Select the level of functionality	+CFUN=[<fun>[,<rst>]]	OK +CME ERROR: <err>

Description	Command	Possible Reponse(s)
Get current level	+CFUN?	+CFUN: <fun> OK +CME ERROR: <err>
Get supported values	+CFUN=?	+CFUN: (list of supported <fun>s), (list of supported <rst>s) OK +CME ERROR: <err>

Parameters

<fun>	Description
1 (default)	Full functionality
4	Disable phone both transmit and receive RF circuits
Omitted	Use previous value

<rst>	Description
0 (default)	Do not reset the MT before setting it to <fun> power level
1	Reset the MT before setting it to <fun> power level

Clarification

AT+CFUN=1,1 resets the mobile. “OK” result code will appear after reset has been completed. AT+CFUN=1,1 has no effect on radio on/off, it leaves it as the same state it was before reset.

AT+CFUN=1,0 requests a radio on and memorize in non volatile memory <fun> level.

AT+CFUN=4,0 requests a radio off and memorize in non-volatile memory <fun> level.

At next switch on, ME will start with the <fun> level of the last +CFUN (i.e radio on or off). This allows TE to have control on radio on/off.

+CFUN parameter is automatically saved into non-volatile memory.

The <fun> parameter is restored to default value by AT&F.

+CPIN Enter PIN

Description	Command	Possible Response(s)
Send password to MT	+CPIN=<pin>[,<newpin>]	OK +CME ERROR: <err>

Description	Command	Possible Response(s)
Check if a password is expected	+CPIN?	+CPIN: <code> +CME ERROR: <err>
Test if command is supported	+CPIN=?	OK +CME ERROR: <err>

Parameters

<code>	Description
READY	MT is not pending for any password
SIM PIN	MT is waiting SIM PIN to be given
SIM PUK	MT is waiting SIM PUK to be given
SIM PIN2	MT is waiting SIM PIN2 to be given This <code> is returned only when the last executed command resulted in PIN2 authentication failure (i.e. +CME ERROR: 17). If PIN2 is not entered right after the failure, MT does not block its operation
SIM PUK2	MT is waiting SIM PUK2 to be given This <code> is returned only when the last executed command resulted in PUK2 authentication failure (i.e. +CME ERROR: 18). If PUK2 and new PIN2 are not entered right after the failure, MT does not block its operation
PH-NET PIN	MT is waiting network personalization password to be given Correspond to NCK code
PH-NETSUB PIN	MT is waiting network subset personalization password to be given Correspond to NSCK code
PH-SP PIN	MT is waiting service provider personalization password to be given Correspond to SPCK code
PH-CORP PIN	MT is waiting corporate personalization password to be given Correspond to CCK code

Clarification

When the pin code is required, the error result code is a CMS ERROR for the AT commands that belong to the 27.005 and a CME ERROR for all the other AT commands

+CPWC Power class

Description	Command	Possible Response(s)
Set power class for corresponding band	+CPWC=[<class>[,<band>]]	OK +CME ERROR: <err>
Get the list of current and default power class for each supported band	+CPWC?	+CPWC: <curr_class1>,<def_class1>,<band1> [,<curr_class2>,<def_class2>,<band2> [...]] OK +CME ERROR: <err>
Get supported values	+CPWC=?	+CPWC: list of supported (<band>,(list of <class>s pair)) OK +CME ERROR: <err>

Parameters

<class> <curr_classn> <def_classn>	Description
Integer type	0 default (not applicable to <curr_class> or <def_classn>) 1…x MT output power class as in GSM 45.005 [38]

<band> <bandn>	Description
Integer type	Frequency band, one of the following: 0 GSM900 1 DCS 1800 2 PCS 1900 (Not supported) 3 GSM850 (Not supported)

Clarification

Action command is effective after a reset.

+CSQ Signal Quality

Description	Command	Possible Response(s)
Get signal information	+CSQ	+CSQ: <rssi>,<ber> OK
Get supported values	+CSQ=?	+CSQ: (list of supported <rssi>s),(list of supported <ber>s) OK

Parameters

<rssi>	Description
0..31	From -113 dBm or less to -51 dBm or greater
99	Not known or not detectable

<ber>	Description
0..7	As RXQUAL values in the table in TS 45.008 [20] subclause 8.2.4
99	Not known or not detectable

Clarification

The <ber> is provided only in online mode.

+CMEC Mobile Termination control mode

Description	Command	Possible Response(s)
Select equipment	+CMEC=[<keyp>[,<disp>[,<ind>]]]	OK +CME ERROR: <err>
Get current settings	+CMEC?	+CMEC: <keyp>,<disp>,<ind> OK +CME ERROR: <err>
Get supported values	+CMEC=?	+CMEC: (list of supported <keyp>s),(list of supported <disp>s),(list of supported <ind>s) OK +CME ERROR: <err>

Parameters

<keyp>	Description
0	MT can be operated only through its keypad. Not relevant on WISMO products; do not use.

<disp>	Description
0	Only MT can write to its display. Not relevant on WISMO products; do not use.

<ind>	Description
0	Only MT can set the status of its indicators (command +CIND can only be used to read the indicators)

+CIND Indicator control

Description	Command	Possible Response(s)
Set MT indicators	+CIND=[<ind>[,<ind>[,…]]]	OK +CME ERROR: <err>
Get MT indicator status	+CIND?	+CIND: <ind>[,<ind>[...]] OK +CME ERROR: <err>
Get supported values	+CIND=?	+CIND: (<descr>,(list of supported <ind>s)) [,(<descr>,(list of supported <ind>s))[...]] OK +CME ERROR: <err>

Parameters

<ind>	Description
Integer type	Range of corresponding <descr>

<descr>	Description
“battchg”	Battery charge level (0-5)
“signal”	Signal quality (0-5)
“service”	Service availability (0-1)
“message”	Message received (0-1)

<descr>	Description
“call”	Call in progress (0-1)
“roam”	Roaming indicator (0-1)
“smsfull”	A short message memory storage in the MT has become full (1), or memory locations are available (0)

Restriction

It is impossible to set indicators value.

+CMER Mobile Termination event reporting

Description	Command	Possible Response(s)
Control URC notifications	+CMER=[<mode>[,<keyp>[,<disp>[,<ind>[,<bfr>]]]]]	OK +CME ERROR: <err>
Get current settings	+CMER?	+CMER: <mode>,<keyp>,<disp>,<ind>,<bfr> OK
Get supported values	+CMER=?	+CMER: (list of supported <mode>s),(list of supported <keyp>s),(list of supported <disp>s),(list of supported <ind>s),(list of supported <bfr>s) OK

Parameters

<mode>	Description
0	Buffer unsolicited result codes in the TA; if TA result code buffer is full, codes can be buffered in some other place or the oldest ones can be discarded
1	Discard unsolicited result codes when TA TE link is reserved (e.g. in on line data mode); otherwise forward them directly to the TE
Omitted	Use previous value

<keyp>	Description
0	No keypad event reporting

<disp>	Description
0	No display event reporting

<ind>	Description
0 (default)	No indicator event reporting
1	Indicator event reporting using result code +CIEV: <ind>,<value>. <ind> indicates the indicator order number (as specified for +CIND) and <value> is the new value of indicator.
2	Indicator event reporting using result code +CIEV: <ind>,<value>. All indicator events shall be directed from TA to TE

<bfr>	Description
0	TA buffer of unsolicited result codes defined within this command is cleared when <mode> 1...3 is entered

+CPBS Select phonebook memory storage

Description	Command	Possible Response(s)
Select phonebook memory storage	+CPBS=<storage>	OK +CME ERROR: <err>
Get current memory storage status	+CPBS?	+CPBS: <storage>[,<used>,<total>] OK +CME ERROR: <err>
Get supported storages	+CPBS=?	+CPBS: (list of supported <storage>s) OK

Parameters

<storage>	Description
DC	MT dialled calls list (+CPBW is not applicable for this storage)
EN	SIM/USIM (or MT) emergency number (+CPBW is not applicable for this storage)
FD	SIM/USIM fixed dialling phonebook. If a SIM card is present or if a UICC with an active GSM application is present, the information in EFFDN under DFTelecom is selected. If a UICC with an active USIM application is present, the information in EFFDN under ADFUSIM is selected.
MC	MT missed (unanswered received) calls list (+CPBW is not applicable for this storage)

<storage>	Description
ON	SIM (or MT) own numbers (MSISDNs) list (reading of this storage may be available through +CNUM also). When storing information in the SIM/UICC, if a SIM card is present or if a UICC with an active GSM application is present, the information in EFMSISDN under DFTelecom is selected. If a UICC with an active USIM application is present, the information in EFMSISDN under ADFUSIM is selected.
RC	MT received calls list (+CPBW is not applicable for this storage)
SM (default)	SIM/UICC phonebook. If a SIM card is present or if a UICC with an active GSM application is present, the EFADN under DFTelecom is selected. If a UICC with an active USIM application is present, the global phonebook, DFPHONEBOOK under DFTelecom is selected.
AP	Selected application phonebook. If a UICC with an active USIM application is present, the application phonebook, DFPHONEBOOK under ADFUSIM is selected

<used>	Description
Integer type	Value indicating the number of used locations in selected memory

<total>	Description
Integer type	Value indicating the total number of locations in selected memory

Clarification

"SM" corresponds to SIM/UICC phonebook (global phonebook) If a SIM card is present or if a UICC with an active GSM application is present, the EFADN under DFTelecom is selected. If a UICC with an active USIM application is present, the global phonebook, DFPHONEBOOK under DFTelecom is selected.

"AP" corresponds to selected application phonebook (local phonebook). If a UICC with an active USIM application is present, the application phonebook, DFPHONEBOOK under ADFUSIM is selected.

When "FD" is selected as <storage>, the SIM PIN2 request is displayed and the request to change <storage> is disregarded. "FD" must be selected as <storage> again after SIM PIN2 has been entered to change <storage>.

+CPBS parameter is automatically saved into non-volatile memory.

The <storage> parameter is restored to default value by AT&F command.

+CPBR Read phonebook entries

Description	Command	Possible Response(s)
Read entries	+CPBR=<index1>[,<index2>]	[+CPBR: <index1>,<number>,<type>, <text>[,<hidden>][,<group>][,<adnumber>][,<adtype>][,<secondtext>][,<email>]] [[...] <CR><LF>+CPBR:<index2>,<number>, <type>,<text> [,<hidden>][,<group>][,<adnumber>][,<adtype>][,<secondtext>][,<email>]]] OK +CME ERROR: <err>
Get location ranges	+CPBR=?	+CPBR: (list of supported<index>s)[,<nlength>][,<tlength>][,<glength>][,<slength>][,<elength>] OK +CME ERROR: <err>

Parameters

<indexn>	Description
Integer type	Values in the range of location numbers of phonebook memory

<number>	Description
String type	Phone number of format <type>

<type>	Description
Integer type	Type of address

<text>	Description
String type	Field of maximum length <tlength> Character set as specified by +CSCS

<hidden>	Description
0	Phonebook entry not hidden
1	Phonebook entry hidden

<group>	Description
String type	Field of maximum length <glength> Character set as specified by +CSCS

<adnumber>	Description
String type	Field of maximum length <slength> Character set as specified by +CSCS

<adtype>	Description
Integer type	Type of address

<secondtext>	Description
String type	Field of maximum length <slength> Character set as specified by +CSCS

<email>	Description
String type	Field of maximum length <elength> Character set as specified by +CSCS

<nlength>	Description
Integer type	Value indicating the maximum length of field <number>

<tlength>	Description
Integer type	Value indicating the maximum length of field <text>

<glength>	Description
Integer type	Value indicating the maximum length of field <group>

<slength>	Description
Integer type	Value indicating the maximum length of field <secondtext>

<elength>	Description
Integer type	Value indicating the maximum length of field <email>

<oper>	Description
String type	Refer to [27.007]

Clarification

Only first <group>,<adnumber>,<adtype>,<secondtext>,<email> are returned with the command.

+CPBF Find phonebook entries

Description	Command	Possible Response(s)
Find entries	+CPBF=<findtext>	[+CPBF: <index1>,<number>,<type>, <text>[,<hidden>][,<group>][,<adnumber>][,<adtype>][,<secondtext>][,<email>]] [[...] <CR><LF>+CPBF:<index2>,<number>,<type>,<text> [,<hidden>][,<group>][,<adnumber>][,<adtype>][,<secondtext>][,<email>]]] OK +CME ERROR: <err>
Get location ranges	+CPBR=?	+CPBF: [<nlength>][,<tlength>][,<glength>][,<slength>][,<elength>] OK +CME ERROR: <err>

Parameters

<findtext>	Description
String type	Field of maximum length <tlength> Character set as specified by +CSCS

For other parameters: refer to +CPBR command.

Clarification

Only first <group>,<adnumber>,<adtype>,<secondtext>,<email> are returned with the command.

+CPBW Write phonebook entry

Description	Command	Possible Response(s)
Write entry	+CPBW=<index>[,<number>[,<type>[,<text>[,<group>[,<adnumber>[,<adtype>[,<secondtext>[,<email>[,<hidden>]]]]]]]]	OK +CME ERROR: <err>
Get location ranges and supported values	+CPBW=?	+CPBW: (list of supported <index>s),[<nlength>],(list of supported <type>s),[<tlength>],[<glength>],[<slength>],[<elength>] OK +CME ERROR: <err>

Parameters

<index>	Description
0..999	Field of maximum length <tlength> Character set as specified by +CSCS

For other parameters: refer to +CPBR command.

Clarification

Only first <group>, <adnumber>, <adtype>, <secondtext>, <email> are returned with the command.

If only <index> is provided, then the phone book entry located at <index> location will be deleted.

+CCLK Clock

Description	Command	Possible Response(s)
Set time	+CCLK=<time>	OK +CME ERROR: <err>
Get current time	+CCLK?	+CCLK: <time> OK
Test if command is supported	+CCLK=?	OK

Parameters

<time>	Description
String type	Format is "yy/mm/dd,hh:mm:ss±zz", where characters indicate year (two last digits), month, day, hours, minutes, seconds and time zone (indicates the difference, expressed in quarters of an hour, between the local time and GMT; range 47...+48). E.g. 6th of May 1994, 22:10:00 GMT+2 hours equals to "94/05/06,22:10:00+08"

+CSIM Generic SIM access

Description	Command	Possible Response(s)
Send command to SIM	+CSIM=<length>,<command>	+CSIM: <length>,<response> OK +CME ERROR: <err>
Test if command is supported	+CSIM=?	OK +CME ERROR: <err>

Parameters

<length>	Description
Integer type	Length of the characters that are sent to TE in <command> or <response> (two times the actual length of the command or response)

<command>	Description
String type	Command passed on by the MT to the SIM in the format as described in GSM 51.01 Hexadecimal character format

<response>	Description
String type	Response to the command passed on by the SIM to the MT in the format as described in GSM 51.011 Hexadecimal character format

Clarification

SIM commands RUN GSM ALGORITHM, TERMINAL PROFILE, ENVELOPE, FETCH and TERMINAL RESPONSE are not supported.

Whatever +CSCS setting, format of <command> and <response> is always hexadecimal. (AT+CSCS="HEX" is not supported)

+CRSM Restricted SIM access

Description	Command	Possible Response(s)
Send command to SIM	+CRSM=<command>[,<fileid>[,<P1>,<P2>,<P3>[,<data>]]]	+CRSM: <sw1>,<sw2>[,<response>] OK +CME ERROR: <err>
Test if command is supported	+CRSM=?	OK

Parameters

<command>	Description
176 (READ BINARY)	Read a transparent EF Transparent file greater than 256 bytes are not supported: →P1 shall always be 0 (ERROR otherwise) →P2 shall be in the range 0-256
178 (READ RECORD)	Read a record Only P2="04" (absolute mode) is supported (Other parameters are not useful).
192 (GET RESPONSE)	Get response If <fileid> is not provided, the command applies to the last selected file
214 (UPDATE BINARY)	Read a transparent EF Only P1="00" and P2="00" is supported
220 (UPDATE RECORD)	Update a record Only P2="03" (previous mode) is allowed for updates on cyclic file (refer to [51.011]). For linear files, only P2="04" (absolute mode) is supported
242 (STATUS)	Status If <fileid> is not provided, the command applies to the last selected file

<fileid>	Description
Integer type	Identifier of an elementary data file on SIM. Mandatory for every command except STATUS

<P1> <P2> <P3>	Description
Integer type	Parameters passed on by the MT to the SIM. These parameters are mandatory for every command, except GET RESPONSE and STATUS

<data>	Description
String type	Information which shall be written to the SIM Hexadecimal character format

<sw1> <sw2>	Description
Integer type	Information from the SIM about the execution of the actual command. These parameters are delivered to the TE in both cases, on successful or failed execution of the command

<response>	Description
String type	Response of a successful completion of the command previously issued. STATUS and GET RESPONSE return data, which gives information about the current elementary data field. After READ BINARY, READ RECORD command the requested data will be returned. <response> is not returned after a successful UPDATE BINARY, UPDATE RECORD or SET DATA command Hexadecimal character format

+CRSL Ringer sound level

Description	Command	Possible Response(s)
Set incoming call ringer sound level	+CRSL=<level>	OK +CME ERROR: <err>
Get current level	+CRSL?	+CRSL: <level> OK +CME ERROR: <err>
Get supported values	+CRSL=?	+CRSL: (list of supported <level>s) OK +CME ERROR: <err>

Parameters

<level>	Description
0..3	Level range

Clarification

The <level> parameter is automatically saved into non-volatile memory.

+CLVL Loudspeaker volume level

Description	Command	Possible Response(s)
Set sound speaker level	+CLVL=<level>	OK +CME ERROR: <err>

Description	Command	Possible Response(s)
Get current level	+CLVL?	+CLVL: <level> OK +CME ERROR: <err>
Get supported values	+CLVL=?	+CLVL: (list of supported <level>s) OK +CME ERROR: <err>

Parameters

<level>	Description
1..10	Level range

Clarification

+CLVL has been replaced by the +VGR command and no longer works on the WISMO218. If +CLVL is used, ERROR will be returned.

+CMUT Mute control

Description	Command	Possible Response(s)
Mute/unmute call	+CMUT=<n>	OK +CME ERROR: <err>
Get current mode	+CMUT?	+CMUT: <n> OK +CME ERROR: <err>
Get supported values	+CMUT=?	+CMUT: (list of supported <n>s) OK

Parameters

<n>	Description
0	Mute off
1	Mute on

+CACM Accumulated call meter

Description	Command	Possible Response(s)
Reset ACM	+CACM=[<passwd>]	OK +CME ERROR: <err>
Get current ACM	+CACM?	+CACM: <acm> OK +CME ERROR: <err>
Test if command is supported	+CACM=?	OK +CME ERROR: <err>

Parameters

<passwd>	Description
String type	SIM PIN2

<acm>	Description
String type	Accumulated call meter value similarly coded as <ccm> under +CAOC

+CAMM Accumulated call meter maximum

Description	Command	Possible Response(s)
Set ACMmax	+CAMM=[<acmmax>[,<passwd>]]	OK +CME ERROR: <err>
Get current ACMmax	+CAMM?	+CAMM: <acm> OK +CME ERROR: <err>
Test if command is supported	+CAMM=?	OK +CME ERROR: <err>

Parameters

<acmmax>	Description
String type	Accumulated call meter maximum value similarly coded as <ccm> under +CAOC; value zero disables ACMmax feature

<passwd>	Description
String type	SIM PIN2

+CPUC Price per unit and currency table

Description	Command	Possible Response(s)
Set price per unit and currency	+CPUC=<currency>,<ppu>[,<passwd>]	OK +CME ERROR: <err>
Get current currency and price per unit	+CPUC?	+CPUC: <currency>,<ppu> OK +CME ERROR: <err>
Test if command is supported	+CPUC=?	OK +CME ERROR: <err>

Parameters

<currency>	Description
String type	Three-character currency code (e.g. "GBP", "DEM"); character set as specified by command +CSCS

<ppu>	Description
String type	Price per unit; dot is used as a decimal separator (e.g. "2.66")

<passwd>	Description
String type	SIM PIN2

+CCWE Call Meter maximum event

Description	Command	Possible Response(s)
Set call meter mode max event	+CCWE=<mode>	OK +CME ERROR: <err>
Get current mode	+CCWE?	+CCWE: <mode> OK +CME ERROR: <err>

Description	Command	Possible Response(s)
Get supported modes	+CCWE=?	+CCWE: (list of supported <mode>s) OK +CME ERROR: <err>

Parameters

<mode>	Description
0	Disable the call meter warning event +CCWV
1	Enable the call meter warning event +CCWV

+CLAN Set Language

Description	Command	Possible Response(s)
Set language	+CLAN=<code>	OK +CME ERROR: <err>
Get current mode	+CLAN?	+CLAN: <code> OK +CME ERROR: <err>
Get supported modes	+CLAN=?	+CLAN:(list of supported <code>s) OK +CME ERROR: <err>

Parameters

<code>	Description
String type	Language coded in ISO 639 format. “AUTO” or 2 double quoted letters. For example “en” for English.

+CSVM Set Voice Mail Number

Description	Command	Possible Response(s)
Set voice mailbox number	+CSVM=<mode>[,<number>[,<type>]]	OK +CME ERROR: <err>

Description	Command	Possible Response(s)
Get current voice mailbox number	+CSVM?	+CSVM:<mode>,<number>,<type> OK +CME ERROR: <err>
Get supported values	+CSVM=?	+CSVM: (list of supported mode>s), (list of supported <type>s) OK +CME ERROR: <err>

Parameters

<mode>	Description
0	Disable the voice mail number i.e delete the voice mailbox number
1	Enable the voice mail number

<number>	Description
String type	Character string 0..9,+

<type>	Description
Integer type	Type of address (129 or 145)

Clarification

+CSVM parameters are automatically saved into non-volatile memory.

+CRMP Ring Melody Playback

Description	Command	Possible Response(s)
Play ring melody	+CRMP=<calltype>[,<volume>[,<type>,<index>]]	OK +CME ERROR: <err>
Get supported values	+CRMP=?	+CRMP: (list of supported <calltype>s),(list of supported <volume>s),(<type>),(list of supported <index>s) OK +CME ERROR: <err>

Parameters

<calltype>	Description
0	Manufacturer specific

<volume>	Description
1..3	Volume

<type>	Description
0	Manufacturer defined

<index>	Description
1..10	Ring melody index
11	Vibrator mode

Clarification

If a melody is played, it is played for 10 seconds and stops.

+CLAC List all available AT commands

Description	Command	Possible Response(s)
List all commands	+CLAC	+CLAC:<CR><LF><AT Command1>[<CR><LF><AT Command2>[…]] OK +CME ERROR: <err>
Test if command is supported	+CLAC=?	OK +CME ERROR: <err>

+CALA Set alarm time

Description	Command	Possible Response(s)
Set alarm	+CALA=<time>[,<n>[,<recurr>]]	OK +CME ERROR: <err>

Description	Command	Possible Response(s)
Read alarm	+CALA?	[+CALA: <time>,<n1>,[<recurr>] [<CR><LF>+CALA: <time>,<n2>,[<recurr>] [...]]] OK +CME ERROR: <err>
Get supported values	+CALA=?	+CALA: (list of supported <time>s),(list of supported <n>s),(list of supported <recur>s) OK +CME ERROR: <err>

Parameters

<time>	Description
07/04/11,11:34:25	Internal clock (Cf. +CCLK) string type "hh:mm:ss" if <recurr> is present or "yy/mm/dd,hh:mm:ss" if not.

<n>, <n1>, <n2>	Description
1..5	Index of the alarm

<recurr>	Description
“0”,”1,..,7”	String type value indicating day of week for the alarm in one of the following formats: "<1..7>[,<1..7>[…]]" – Sets a recurrent alarm for one or more days in the week. The digits 1 to 7 corresponds to the days in the week, Monday (1), …, Sunday (7). Example: The string "1,2,3,4,5" may be used to set an alarm for all weekdays. "0" sets a recurrent alarm for all days in the week.

Clarification

Set command sets an alarm time in the MT. If setting fails in an MT error, +CME ERROR: <err> is returned. To set up a recurrent alarm for one or more days in the week, the <recurr>-parameter may be used.

When an alarm is timed out and executed, the unsolicited result code +CALV: <n> is always returned. Read command returns the list of current active alarm settings in the MT. Test command returns the supported syntax.

+CALD Delete alarm

Command	Possible Response(s)
+CALD=<n>	OK +CME ERROR: <err>
+CALD=?	+CALD: (list of supported <n>s) OK+CME ERROR: <err>

Parameters

<n>	Description
1..5	Integer type value indicating the index of the alarm

Clarification

Action command deletes an alarm in the MT. If the command fails in an MT error, +CME ERROR: <err> is returned. Test command returns supported index values.

Control and Status Result Codes

+CCWV Call Meter warning value

Description	Result code
Call meter warning value	+CCWV

Parameters

<ccm>	Description
String type	Three bytes of the current call meter value in hexadecimal format (e.g. "00001E" indicates decimal value 30); value is in home units and bytes are similarly coded as ACMmax value in the SIM card or in the active application in the UICC (GSM or USIM)

Clarification

This warning will be triggered shortly before the ACM (Accumulated Call Meter) maximum value is reached, an unsolicited result code +CCWV will be sent, if enabled by +CCWE command. The warning is issued approximately when 30 seconds call time remains. It is also issued when starting a call if less than 30 seconds call time remains.

+CIEV Indicator event report

Description	Result code
Event report	+CIEV: <ind>,<value>

Parameters

<ind>	Description
0	Battery level
1	Signal strength

<value>	Description
0..5	Range of value for <ind>=0
0..4	Range of value for <ind>=1

Mobile Termination Error Control

+CMEE Report Mobile Equipment error

Description	Command	Possible Response(s)
Set error mode	+CMEE=[<n>]	OK +CME ERROR: <err>
Get current mode	+CMEE?	+CMEE: <n> OK
Get supported values	+CMEE=?	+CMEE: (list of supported <n>s) OK

Parameters

<mode>	Description
0	Disable +CME ERROR: <err> result code and use ERROR instead

<mode>	Description
1	Enable +CME ERROR: <err> result code and use numeric <err> values
2	Enable +CME ERROR: <err> result code and use verbose <err> values

Mobile Termination Error Result Code

+CME ERROR

Description	Result code
Error type	+CME ERROR: <err>

General error

Numeric mode	Verbose Mode
0	Phone failure
1	No connection to phone
2	Phone-adaptor link reserved
3	Operation not allowed
4	Operation not supported
5	PH-SIM PIN required
6	PH-FSIM PIN required
7	PH-FSIM PUK required
10	SIM not inserted (Note)
11	SIM PIN required
12	SIM PUK required
13	SIM failure (Note)
14	SIM busy (Note)
15	SIM wrong (Note)
16	Incorrect password
17	SIM PIN2 required

Numeric mode	Verbose Mode
18	SIM PUK2 required
20	Memory full
21	Invalid index
22	Not found
23	Memory failure
24	Text string too long
25	Invalid characters in text string
26	Dial string too long
27	Invalid characters in dial string
30	No network service
31	Network timeout
32	Network not allowed - emergency calls only
40	Network personalization PIN required
41	Network personalization PUK required
42	Network subset personalization PIN required
43	Network subset personalization PUK required
44	Service provider personalization PIN required
45	Service provider personalization PUK required
46	Corporate personalization PIN required
47	Corporate personalization PUK required
50	Incorrect parameters
99	Resource limitation (for +CCWA command only)
100	Unknown

NOTE: This error code is also applicable to UICC.

GPRS-related error

Numeric mode	Verbose Mode
103	Illegal MS
106	Illegal ME
107	GPRS services not allowed
111	PLMN not allowed
112	Location area not allowed
113	Roaming not allowed in this location area
132	Service option not supported
133	Requested service option not subscribed
134	Service option temporarily out of order
149	PDP authentication failure
150	Invalid mobile class
148	Unspecified GPRS error

Commands for Packet Domains

+CGDCONT Define PDP Context

Description	Command	Possible Response(s)
Define a PDP	+CGDCONT=[<cid>[,<PDP_type>[,<APN>[,<PDP_addr>[,<d_comp>[,<h_comp>]]]]]]	OK +CME ERROR: <err>
List current defined PDP	+CGDCONT?	+CGDCONT: <cid>, <PDP_type>, <APN>,<PDP_addr>, <data_comp>,<head_comp> [<CR><LF>+CGDCONT: <cid>, <PDP_type>, <APN>,<PDP_addr>, <data_comp>,<head_comp> [...]] OK +CME ERROR: <err>

Description	Command	Possible Response(s)
Get supported values	+CGDCONT=?	+CGDCONT: (range of supported <cid>s), <PDP_type>,,,(list of supported <d_comp>s), (list of supported <h_comp>s) [<CR><LF>+CGDCONT: (range of supported <cid>s), <PDP_type>,,,(list of supported <d_comp>s), (list of supported <h_comp>s) [...]] OK +CME ERROR: <err>

Parameters

<cid>	Description
1	PDP Context Identifier 1 Definition stored in non-volatile memory
2	PDP Context Identifier 2 Definition stored in non-volatile memory
3 (default)	PDP Context Identifier 3 Locked in non-volatile memory and is always defined.

<PDP_type>	Description
“IP”	Internet Protocol (IETF STD 5)
“PPP”	Point to Point Protocol (IETF STD 51)

<APN>	Description
String type	Access Point Name If the value is null or omitted, then the subscription value will be requested

<PDP_addr>	Description
String type	IP address Format: "<n>.<n>.<n>.<n>" where <n>=0..255 If the value is null or equals 0.0.0.0 a dynamic address will be requested. The allocated address may be read using the +CGPADDR command

<d_comp>	Description
0	PDP data compression off Default if value is omitted

<h_comp>	Description
0	PDP header compression off Default if value is omitted

Clarification

For <cid> 1,2 and 3, PDP context definition is stored in EEPROM i.e parameters provided in +CGDCONT for PDP context definition and PDP context status (defined/undefined) are stored in non-volatile memory (If a PDP has been defined with +CGDCONT, after a switch off / switch on, AT+CGDCONT? will list the PDP has defined).

<cid> 3 is locked. This means that TE is not allowed to modify definition and parameters of <cid>=3 with +CGDCONT set command. This gives a default PDP context with parameters that TE cannot change .

<cid> 3 is also the default <cid>: if +CGDCONT with <cid> omitted is received, <cid> 3 will be used.

+CGDCONT parameters are automatically saved into non-volatile memory.

+CGQREQ Quality of Service Profile (Requested)

Description	Command	Possible Response(s)
Set requested QOS (R97)	+CGQREQ=[<cid> [,<precedence>[,<delay> [,<reliability>[,<peak> [,<mean>]]]]]]	OK +CME ERROR: <err>
Get current settings	+CGQREQ?	+CGQREQ: <cid>,<precedence >,<delay>, <reliability>,<peak>,<mean> [<CR><LF>+CGQREQ: <cid>,<precedence>,<delay>,<reliability>, <peak>, <mean> […]] OK +CME ERROR: <err>

Description	Command	Possible Response(s)
Get supported values	+CGQREQ=?	+CGQREQ: <PDP_type>, (list of supported <precedence>s),(list of supported <delay>s), (list of supported <reliability>s) ,(list of supported <peak>s),(list of supported <mean>s) [<CR><LF>+CGQREQ: <PDP_type>,(list of supported <precedence>s),(list of supported <delay>s),(list of supported <reliability>s), (list of supported <peak>s),(list of supported <mean>s) […]] OK +CME ERROR: <err>

Parameters

<cid>	Description
1..3	PDP Context Identifier Definition stored in non-volatile memory (refer to +CGDCONT)

<precedence>	Description
0 (default)	QOS precedence class subscribed value
1..3	QOS precedence class

<delay>	Description
0 (default)	QOS delay class subscribed value
1..4	QOS delay class subscribed

<reliability>	Description
0	QOS reliability class subscribed value
1..5	QOS reliability class Default value: 3

<peak>	Description
0 (default)	QOS peak throughput class subscribed value
1..9	QOS peak throughput class

<mean>	Description
0 (default)	QOS mean throughput class subscribed value
1..18	QOS mean throughput class
31	QOS mean throughput class best effort

Clarification

Refer to § 6.1.2 for QoS mapping between R99 and R97/R98 QoS.

+CGQMIN Quality of Service Profile (Minimum acceptable)

Description	Command	Possible Response(s)
Set minimum QOS (R97)	+CGQMIN=[<cid> [,<precedence>[,<delay> [,<reliability>[,<peak> [,<mean>]]]]]]	OK +CME ERROR: <err>
Get current settings	+CGQMIN?	+CGQMIN: <cid>,<precedence>,<delay>, <reliability>,<peak>,<mean> [<CR><LF>+CGQMIN: <cid>,<precedence>, <delay>,<reliability>,<peak>,<mean> […]] OK +CME ERROR: <err>
Get supported values	+CGQMIN=?	+CGQMIN: <PDP_type>, (list of supported <precedence>s),(list of supported <delay>s), (list of supported <reliability>s),(list of supported <peak>s),(list of supported <mean>s) [<CR><LF>+CGQMIN: <PDP_type>, (list of supported <precedence>s),(list of supported <delay>s),(list of supported <reliability>s), (list of supported <peak>s),(list of supported <mean>s) […]] OK +CME ERROR: <err>

Parameters

Refer to +CGQREQ

Clarification

Refer to § 6.1.2 for QoS mapping between R99 and R97/R98 QoS.

+CGATT PS attach or detach

Description	Command	Possible Response(s)
Attach or detach	+CGATT=[<state>]	OK +CME ERROR: <err>
Get current state	+CGATT?	+CGATT: <state> OK +CME ERROR: <err>
Get supported states	+CGATT=?	+CGATT: (list of supported <state>s) OK +CME ERROR: <err>

Parameters

<state>	Description
0 (default)	Detached
1	Attached

+CGACT PDP context activate or deactivate

Description	Command	Possible Response(s)
Activate or deactivate a PDP	+CGACT=[<state> [,<cid>[,<cid>[,…]]]]	OK +CME ERROR: <err>
Get current PDPs state	+CGACT?	+CGACT: <cid>,<state> [<CR><LF>+CGACT: <cid>,<state> [...]] OK +CME ERROR: <err>
Get supported states	+CGACT=?	+CGACT: (list of supported <state>s) OK +CME ERROR: <err>

Parameters

<state>	Description
0	Deactivated
1	Activated

<cid>	Description
1..3	PDP Context Identifier

Clarification

This command is used to tests PDPs with network simulators. Successful activation of PDP on real network is not guaranteed.

Refer to +CGDATA clarification for more information.

+CGCMOD PDP Context Modify

Description	Command	Possible Response(s)
Request PDP context modification	+CGCMOD=[<cid>[,<cid>[,…]]]	OK +CME ERROR: <err>
Get active PDPs	+CGCMOD=?	+CGCMOD: (list of <cid>s associated with active contexts) OK +CME ERROR: <err>

Parameters

<cid>	Description
1..3	PDP Context Identifier

Clarification

Recommendation specifies that after the command has completed, the MT returns to online data state but "OK" result code is expected: this seems inconsistent.

From Sierra Wireless point of view, +CGCMOD behaviour is more similar to +CGACT command, hence the implementation choice is not to switch link to online data mode after PDP context modification.

TE will have to send +++ escape sequence to switch channel to online command if +CGCMOD cannot be performed from another AT channel. TE will have to use O command, if required, to switch channel to online data mode.

+CGDATA Enter data state

Description	Command	Possible Response(s)
Enter data state	+CGDATA[=<L2P>,[<cid>]]	CONNECT +CME ERROR: <err>

Description	Command	Possible Response(s)
Get supported values	+CGDATA=?	+CGDATA: (list of supported <L2P>s) OK +CME ERROR: <err>

Parameters

<L2P>	Description
"PPP"	Point-to-point protocol for a PDP such as IP

<cid>	Description
1..3	PDP Context Identifier

Clarification

If no parameters are provided (i.e +CGDATA<CR>), the last <cid> activated with +CGACT or the default <cid> is used.

Only one <cid> in the command is supported (i.e +CGDATA="PPP", <cid><CR>)

This command is used for PDP tests on network emulators. On real network functioning of +CGACT and then +CGDATA for data transfer is not guaranteed.

+CGDATA implementation does not perform PS attach or PDP context activation. The PDP identified by <cid>, when provided, in +CGDATA must have been activated previously thanks to +CGACT command.

+CGDATA only switches channel to online data mode and open PPP server in a proprietary mode called "FTA mode" (In this mode PPP only acts a relay).

For IP over PPP services, ATD*98 or ATD*99 commands must be used: when activating a PDP context, PCO (protocol configuration option) has to be provided to network. PCO can be provided to network only if a PPP negotiation (LCP/NCP negotiation) has been initiated between mobile and TE before PDP activation (refer to TS 27.060 §9.1). This negotiation is possible only if AT channel is switched to online data mode before PDP context activation. Hence, the PDP identified with <cid> in +CGDATA should not have been activated by +CGACT ➔ not possible in the current implementation (+CGDATA does not behaves as ATD*9x when <cid> is not activated)

To go back in online command, the "+++" escape sequence has to be sent on link in data mode

+CGDATA can also be used to switch again channel to online data mode (after "+++") if PDP is still active (same behaviour has ATO command).

PDP test use case:

AT commands	Comments
AT+CGACT=1,1 OK	PDP 1 is activated No PCO negotiation

AT commands	Comments
AT+CGDATA CONNECT	PPP server is opened in FTA mode, channel is switched in online data mode No LCP/NCP negotiation
Data transfer	
+++ OK	Channel is back to online command mode
ATH OK	PPP server FTA mode is closed but PDP is NOT deactivated
AT+CGACT=0,1 OK	PDP 1 is deactivated. (If ATH is not sent before deactivation, +CGACT returns ERROR)

+CGPADDR Show PDP address

Description	Command	Possible Response(s)
Get PDP addresses	+CGPADDR=[<cid> [,<cid> [,…]]]	+CGPADDR: <cid>,<PDP_addr> [<CR><LF>+CGPADDR: <cid>,<PDP_addr> [...]] OK +CME ERROR: <err>
Get defined <cid>	+CGPADDR=?	+CGPADDR: (list of defined <cid>s) OK +CME ERROR: <err>

Parameters

<cid>	Description
1..3	PDP Context Identifier

<PDP_addr>	Description
String type	IP address Format: "<n>.<n>.<n>.<n>" where <n>=0..255

Clarification

Set command return address provided by the network if a connection has been established.

+CGCLASS GPRS mobile station class

Description	Command	Possible Response(s)
Set mode of operation	+CGCLASS=[<class>]	OK +CME ERROR: <err>
Get current mode	+CGCLASS?	+CGCLASS: <class> OK +CME ERROR: <err>
Get supported mode	+CGCLASS=?	+CGCLASS: (list of supported <class>s) OK +CME ERROR: <err>

Parameters

<class>	Description
“B” (default)	Class-B mode of operation (A/Gb mode), (not applicable in Iu mode) MT would operate PS and CS services but not simultaneously
“CC”	Class-C mode of operation in CS only mode (A/Gb mode), or CS (Iu mode) (lowest mode of operation) MT would only operate CS services

+CGREG GPRS network registration status

Description	Command	Possible Response(s)
Set registration notification mode	+CGREG=[<n>]	OK +CME ERROR: <err>
Get current registration information	+CGREQ?	+CGREG: <n>,<stat>[,<lac>,<ci>] OK +CME ERROR: <err>
Get supported values	+CGREG=?	+CGREG: (list of supported <n>s) OK +CME ERROR: <err>

Parameters

<n>	Description
0 (default)	Disable network registration unsolicited result code
1	Enable network registration unsolicited result code +CGREG: <stat>
2	Enable network registration and location information unsolicited result code +CGREG: <stat>[,<lac>,<ci>]

<stat>	Description
0	Not registered, MT is not currently searching an operator to register to The GPRS service is disabled, the UE is allowed to attach for GPRS if requested by the user
1	Registered, home network
2	Not registered, but MT is currently trying to attach or searching an operator to register to The GPRS service is enabled, but an allowable PLMN is currently not available. The UE will start a GPRS attach as soon as an allowable PLMN is available.
3	Registration denied The GPRS service is disabled, the UE is not allowed to attach for GPRS if requested by the user.
4	Unknown
5	Registered, roaming

<lac>	Description
String type	Two bytes location area code in hexadecimal format (e.g. "00C3" equals 195 in decimal)

<ci>	Description
String type	Two bytes cell ID in hexadecimal format

Clarification

+CGREG parameter is automatically saved into non-volatile memory.

The <n> parameter is restored to default value by AT&F command.

+CGSMS Select service for MO SMS messages

Description	Command	Possible Response(s)
Set SMS service	+CGSMS= <service>	OK +CME ERROR: <err>
Get current service	+CGSMS?	+CGSMS: <service> OK +CME ERROR: <err>
Get supported values	+CGSMS=?	+CGSMS: (list of currently available <service>s) OK +CME ERROR: <err>

Parameters

<service>	Description
0	Packet Domain
1	Circuit Switched
2	Packet Domain preferred (use Circuit Switched if GPRS not available)
3	Circuit Switched preferred (use Packet Domain if Circuit Switched not available)

Clarification

When <service> value is 2, the SMS is sent on GPRS network if already attached. Otherwise it is sent on circuit switched network. If an error occurs on the GPRS network, no further attempt is made.

Request Packet Domain service 'D'

Description	Command	Possible Response(s)
Request packet domain service	D*99[*[<called_address>][*[<L2P>][*[<cid>]]]]#	CONNECT +CME ERROR: <err>

Parameters

<called_address>	Description
String type	Called party in the address space applicable to the PDP Only empty string is allowed.

<L2P>	Description
1	PPP

<cid>	Description
1..3	PDP Context Identifier

Clarification

If <cid> omitted, default <cid> (3) will be used.

If <cid> correspond to an already active PDP context (activated with +CGACT command) ERROR will be returned, the PDP must be in quiescent state before ATD*9x.

Request Packet Domain IP service 'D'

Description	Command	Possible Response(s)
Request packet domain IPservice	D*98[*<cid>]#	CONNECT +CME ERROR: <err>

Parameters

<cid>	Description
1..3	PDP Context Identifier

Clarification

If <cid> omitted, default <cid> (3) will be used.

If <cid> correspond to an already active PDP context (activated with +CGACT command) ERROR will be returned, the PDP must be in quiescent state before ATD*9x.

+CGEREP Packet Domain event reporting

Description	Command	Possible Response(s)
Set +CGEV notification mode	+CGEREP=[<mode>[,<bfr>]]	OK +CME ERROR: <err>
Get current settings	+CGEREP?	+CGEREP: <mode>,<bfr> OK +CME ERROR: <err>

Description	Command	Possible Response(s)
Get supported values	+CGEREP=?	+CGEREP: (list of supported <mode>s),(list of supported <bfr>s) OK +CME ERROR: <err>

Parameters

<mode>	Description
0 (default)	Buffer unsolicited result codes in the MT; if MT result code buffer is full, the oldest ones are discarded.
1	Discard unsolicited result codes when MT TE link is reserved (e.g. in on line data mode); otherwise forward them directly to the TE
2	Buffer unsolicited result codes in the MT when MT TE link is reserved (e.g. in on line data mode) and flush them to the TE when MT TE link becomes available; otherwise forward them directly to the TE

<bfr>	Description
0 (default)	MT buffer of unsolicited result codes defined within this command is cleared when <mode> 1 or 2 is entered
1	MT buffer of unsolicited result codes defined within this command is flushed to the TE when <mode> 1 or 2 is entered

Clarification

+CGEREP parameters are automatically saved into non-volatile memory.

Packet Domains Result Codes

+CGREG registration status

Description	Result code
Registration change	+CGREG: <stat>[,<lac>,<ci>]

Parameters

<stat>	Description
0	Not registered, MT is not currently searching an operator to register to The GPRS service is disabled, the UE is allowed to attach for GPRS if requested by the user
1	Registered, home network
2	Not registered, but MT is currently trying to attach or searching an operator to register to The GPRS service is enabled, but an allowable PLMN is currently not available. The UE will start a GPRS attach as soon as an allowable PLMN is available.
3	Registration denied The GPRS service is disabled, the UE is not allowed to attach for GPRS if requested by the user.
4	Unknown
5	Registered, roaming

<lac>	Description
String type	Two bytes location area code in hexadecimal format (e.g. "00C3" equals 195 in decimal)

<ci>	Description
String type	Two bytes cell ID in hexadecimal format

4. ITU-T V25.ter Commands

Call Control

A Answer

Description	Command	Possible Response(s)
Answer a MT call	A	OK ERROR

D Dial

Description	Command	Possible Response(s)
Initiate a MO call	D[<dialstring>][;]	OK CONNECT[<speed>] BUSY NO CARRIER NO ANSWER NO DIALTONE +CME ERROR: <err>

Parameters

<dialstring>	Description
Dialling digits	0 1 2 3 4 5 6 7 8 9 * # + A B C ,

<speed>	Description
9600	Data call baudrate

Clarification

The result code "OK" can be sent immediately after call setup or only once call is connected to remote party. Refer to *PSCSSC command for more details.

Semicolon character (;) shall be added when voice call is originated.

D> Direct dialling from phone book

Description	Command	Possible Response(s)
Initiate a MO call	D><str>[;] D>[<mem>]<n>[;]	OK CONNECT[<speed>] BUSY NO CARRIER NO ANSWER NO DIALTONE +CME ERROR: <err>

Parameters

<str>	Description
String	Alphanumeric string with double quotes

<mem>	Description
Memory	Memory storage (“ME”, “SM”)

<n>	Description
index	Memory location index

<speed>	Description
9600	Data call baudrate

H Hang up

Description	Command	Possible Response(s)
Hang up a call	H[<value>]	OK +CME ERROR: <err>

Parameters

<value>	Description
0 (default value)	Disconnect all calls on the channel the command is requested. All active or waiting calls, CS data calls, GPRS call of the channel will be disconnected.

<value>	Description
1	Disconnect all calls on all connected channels. All active or waiting calls, CSD calls, GPRS call will be disconnected (clean up of all calls of the ME).
2	Disconnect all connected CS data call only on the channel the command is requested. Speech calls (active or waiting) or GPRS calls are not disconnected.
3	Disconnect all connected GPRS calls only on the channel the command is requested. Speech calls (active or waiting) or CS data calls are not disconnected.
4	Disconnect all CS calls (either speech or data) but does not disconnect waiting call (either speech or data) on the channel the command is requested.
5	Disconnect waiting call (either speech or data) but does not disconnect other active calls (either CS speech, CS data or GPRS) on the channel the command is requested. (Rejection of incoming call).

Clarification

Note: Voice call disconnection is also dependant of +CVHU settings.

L Monitor speaker loudness

Description	Command	Possible Response(s)
Set Loudness	L[<volume>]	OK +CME ERROR: <err>

Parameters

<volume>	Description
0..9	Volume

Clarification

This command is supported for compatibility purpose and has no effect on ME (simple response OK)

M Monitor speaker mode

Description	Command	Possible Response(s)
Set mode	M[<mode>]	OK +CME ERROR: <err>

Parameters

<mode>	Description
0..9	Mode

Clarification

This command is supported for compatibility purpose and has no effect on ME (simple response OK)

O Online

Description	Command	Possible Response(s)
Switch to online mode	O[<type>]	CONNECT[<speed>] NO CARRIER

Parameters

<type>	Description
0 (default value)	Return to online data state from online command state.

<speed>	Description
9600	Data rate

P Pulse dialing

Description	Command	Possible Response(s)
Pulse dialing	P	OK

Clarification

This command is supported for compatibility purpose and has no effect on ME (simple response OK)

S0 Automatic Answer

Description	Command	Possible Response(s)
Set automatic answer	S0=<num>	OK +CME ERROR: <err>

Description	Command	Possible Response(s)
Read current register value	S0?	<num> OK +CME ERROR: <err>

Parameters

<num>	Description
0 (default)	No automatic answer
1..255	Number of rings the modem will wait for before answering the phone if a ring is detected

Clarification

The <num> parameter is saved into non-volatile memory by AT&W command and restored to default value by AT&F command.

S6 Pause before blind dialing

Description	Command	Possible Response(s)
Set pause duration	S6=<time>	OK +CME ERROR: <err>

Parameters

<time>	Description
0..999	Time

Clarification

This command is supported for compatibility purpose and has no effect on ME (simple response OK)

S7 connection completion timeout

Description	Command	Possible Response(s)
Set timeout	S7=<time>	OK +CME ERROR: <err>
Read current register value	S7?	<time> OK +CME ERROR: <err>

Parameters

<time>	Description
1..255	Amount of time the modem will wait for the carrier signal from the remote modem. If a carrier is not received in this time, the modem will hang up and send the NO CARRIER result code.

S8 Comma dial modifier

Description	Command	Possible Response(s)
Set time	S8=<time>	OK +CME ERROR: <err>
Read current register value	S8?	<time> OK +CME ERROR: <err>

Parameters

<time>	Description
0..255	Amount of time the modem will pause when it detects a comma in the dialling string

Clarification

Comma is not supported in dial string; this command has no effect on ME (simple response OK).

S10 Automatic disconnect delay

Description	Command	Possible Response(s)
Set time	S10=<time>	OK +CME ERROR: <err>
Read current register value	S10?	<time> OK +CME ERROR: <err>

Parameters

<time>	Description
0..255	Amount of time from when the modem recognizes a loss of carrier to when it will hang up

Clarification

This command is supported for compatibility purpose and has no effect on ME (simple response OK)

T Tone dialing

Description	Command	Possible Response(s)
Set dial tone	T	OK

Clarification

This command is supported for compatibility purpose and has no effect on ME (simple response OK)

General TA Control Commands

A/ Repeat last command

Description	Command	Possible Response(s)
Repeat the last command line	A/	Same as the last command

I Identification information

Description	Command	Possible Response(s)
Request identification information	I[<value>]	<text> OK +CME ERROR: <err>

Parameters

<value>	Description
0 (default)	Get model id (WISMO218)
1	Ignored
2	Ignored
3	Get software version (L02_00gg.WISMO218 250509)
4	Get manufacturer id and model id (WAVECOM MODEM WISMO218)
5	Get manufacturer id (WAVECOM MODEM)
6..7	Ignored

Z Reset default configuration

Description	Command	Possible Response(s)
Reset to default configuration	Z[<value>]	OK +CME ERROR: <err>

Parameters

<value>	Description
0 (default value)	Restore profile 0
1	Restore profile 1

Clarification

Parameter impacted by Z command:

Command	Parameter name	Default value
E	<echo>	0x01
Q	<result>	0x00
V	<format>	0x01
X	<result>	0x04
&C	<behavior>	0x01
&D	<behavior>	1
&S	<override>	0
&R	<option>	0x01
+IFC	<TA_by_TE>	0x00
+IFC	<TE_by_TA>	0x02
&K	<mode>	0x00
+FCLASS	<class>	0x00
S0	<num>	0x00
S1	<num>	0x00
S3	<char>	0x0D
S4	<char>	0x0A

Command	Parameter name	Default value
S5	<char>	0x08
S7	<time>	0x64
S8	<time>	0x02
S10	<time>	0x0E

&F Factory defined configuration

Description	Command	Possible Response(s)
Reset to factory configuration	&F[<value>]	OK +CME ERROR: <err>

Parameters

<value>	Description
0 (default value)	Set to factory configuration

Clarification

Parameter impacted by &F command:

Command	Parameter name	Default value
E	<echo>	0x01
Q	<result>	0x00
V	<format>	0x01
X	<result>	0x04
&S	<override>	0x00
+IFC	<TA_by_TE>	0x00
+IFC	<TE_by_TA>	0x02
&K	<mode>	0x00
S0	<num>	0x00
S1	<num>	0x00

Command	Parameter name	Default value
S3	<char>	0x0D (13)
S4	<char>	0x0A (10)
S5	<char>	0x08
S7	<time>	0x64
S8	<time>	0x02
S10	<time>	0x0E
+CRLP	<ver>	0x00
+CRLP	<T4>	0x07
+CRLP	<iws>	0x3D(61)
+CRLP	<mws>	0x3D(61)
+CRLP	<T1>	0x30(48)
+CRLP	<N2>	0x06
+CEER	<cause_select >	0x00
+CEER	<cause >	0x00
+CPBS	<storage>	“SM”
+CSMP	<fo>	0x11(17)
+CSMP	<vp>	0xA7(167)
+CSMP	<pid>	0x00
+CSMP	<dcs>	0x00
+CR	<mode>	0x00
+CSTA	<type>	0x81
+CBST	<speed>	0x07
+CBST	<name>	0x00
+CBST	<ce>	0x01
+CRC	<mode>	0x00
+CMOD	<mode>	0x00
+CMEE	<n>	0x00

Command	Parameter name	Default value
+CREG	<n>	0x00
+CGREG	<n>	0x00
+CSMS	<service>	0x00
+CMER	<ind>	0x00
+CMER	<mode>	0x00
+CMGF	<mode>	0x00
+CSDH	<show>	0x00
+CSCS	<chset>	“IRA”
+CVHU	<mode>	0x00
+CLIR	<n>	0x00
+CLIP	<n>	0x00
+COLP	<n>	0x00
+CSSN	<n>	0x00
+CSSN	<m>	0x00
+CFUN	<fun>	0x01
+PSSREP	<act>	0x00
&C	<behaviour>	0x01
&D	<behaviour>	0x01
&R	<option>	0x01

+GCAP Complete capabilities list

Description	Command	Possible Response(s)
Get list	+GCAP	+GCAP:<list> OK ERROR

Parameters

<list>	Description
String type	List of capabilities: +FCLASS,+CGSM

+GMI Manufacturer identification

Description	Command	Possible Response(s)
Get manufacturer id	+GMI	<manufacturer> OK
Test if command is supported	+GMI=?	OK

Parameters

<manufacturer>	Description
String type	Manufacturer id (WAVECOM MODEM)

+GMM Model identification

Description	Command	Possible Response(s)
Get model id	+GMM	<model> OK
Test if command is supported	+GMM=?	OK

Parameters

<model>	Description
String type	Model id (WISMO218)

+GMR Revision identification

Description	Command	Possible Response(s)
Get model id	+GMR	<revision> OK
Test if command is supported	+GMR=?	OK

Parameters

<revision>	Description
String type	Revision id (B02d00gg.WISMO218 250509)

+GSN Serial number identification

Description	Command	Possible Response(s)
Get model id	+GSN	<sn> OK
Test if command is supported	+GSN=?	OK

Parameters

<sn>	Description
String type	IMEI (15 digits)

TA-TE Interface Commands

E Echo

Description	Command	Possible Response(s)
Control echo	E[<echo>]	OK ERROR

Parameters

<echo>	Description
0	Characters echo disabled
1 (default)	Characters echo enabled
Omitted	<echo> 0 is used

Clarification:

E parameter is saved into non-volatile memory using AT&W command and restored to default value by AT&F command.

Q Result code suppression

Description	Command	Possible Response(s)
Control result code	Q[<result>]	OK ERROR

Parameters

<result>	Description
0 (default)	Result codes are transmitted to TE
1	Result codes are suppressed

Clarification

Q parameter is saved into non-volatile memory by AT&W command and restored to default value by AT&F command.

S3 Line termination character

Description	Command	Possible Response(s)
Set line termination character	S3=<char>	OK ERROR
Get current value	S3?	<char> OK

Parameters

<char>	Description
13 (default)	Termination character <CR>

Clarification

S3 parameter is saved into non-volatile memory by AT&W command and restored to default value by AT&F command.

S4 Response formatting character

Description	Command	Possible Response(s)
Set response formatting character	S4=<char>	OK ERROR
Get current value	S4?	<char> OK

Parameters

<char>	Description
10 (default)	Termination character <LF>

Clarification

S4 parameter is saved into non-volatile memory by AT&W command and restored to default value by AT&F command.

S5 Line editing character

Description	Command	Possible Response(s)
Set line editing character	S5=<char>	OK ERROR
Get current value	S5?	<char> OK

Parameters

<char>	Description
8 (default)	Editing character <BS>

Clarification

S5 parameter is saved into non-volatile memory by AT&W command and restored to default value by AT&F command.

V TA response format

Description	Command	Possible Response(s)
Set response format	V[<format>]	OK 0 ERROR 4

Parameters

<format>	Description
0	Responses in numeric format
1	Responses in verbose format
Omitted	<format> 0 is used

X Result code selection and call progress monitoring

Description	Command	Possible Response(s)
Set result code selection	X[<result>]	OK ERROR

Parameters

<result>	Description
0	CONNECT result code is given upon entering online data state. Dial tone and busy detection are disabled.
1	CONNECT <text> result code is given upon entering online data state. Dial tone and busy detection are disabled.
2	CONNECT <text> result code is given upon entering online data state. Dial tone detection is enabled, and busy detection is disabled.
3	CONNECT <text> result code is given upon entering online data state. Dial tone detection is disabled, and busy detection is enabled.
4	CONNECT <text> result code is given upon entering online data state. Dial tone and busy detection are both enabled.

&C DCD behaviour

Description	Command	Possible Response(s)
Set DCD behaviour	&C<behaviour>	OK ERROR

Parameters

<behaviour>	Description
0	DCE always presents the ON condition on circuit 109.
1 (default)	Circuit 109 changes in accordance with the underlying DCE.

Clarification

&C parameter is saved into non-volatile memory by AT&W command and restored to default value by AT&F command.

&D DTR behaviour

Description	Command	Possible Response(s)
Set DTR behaviour	&D<behaviour>	OK ERROR

Parameters

<behaviour>	Description
0	DCE ignores circuit 108/2.
1	Upon an on-to-off transition of circuit 108/2, the DCE enters online command state and issues an OK result code; the call remains connected. Not supported.
2 (default)	Upon an on-to-off transition of circuit 108/2, the DCE instructs the underlying DCE to perform an orderly cleardown of the call

Clarification

In case of “Drop DTR”, if the signal remains in the off state more than two seconds, it is considered as a PC disconnection and no “OK” is sent to the TE (cable considered unplugged).

The behaviour of the command complies to the recommendation description only with DTR pulses (pulse means DTR signal stays in the off state less than two seconds).

&D parameter is saved into non-volatile memory by AT&W command and restored to default value by AT&F command.

+IPR Fixed TE rate

Description	Command	Possible Response(s)
Set TE rate	+IPR=<rate>	OK ERROR
Get current rate	+IPR?	+IPR: <rate> OK
Get supported values	+IPR=?	+IPR: (list of supported auto-detectable <rate>s)[,(list of supported fixed-only <rate>s)] OK

Parameters

<rate>	Description
0	Automatic rate detection
1200	1200 bps
2400	2400 bps
4800	4800 bps
9600	9600 bps
19200	19200 bps
38400	38400 bps
57600	57600 bps
115200 (default)	115200 bps

Clarification

+IPR parameter is automatically saved in non-volatile memory.

+ICF TE-TA character framing

Description	Command	Possible Response(s)
Set TE-TA character framing	+ICF=[<format>[,<parity>]]	OK +CME ERROR: <err>
Get current value	+ICF?	+ICF: <format>,<parity> OK

Description	Command	Possible Response(s)
Get supported values	+ICF=?	+ICF: (list of supported <format>s),(list of supported<parity>s) OK

Parameters

<format>	Description
3 (default)	8 data bits, 1 stop bit

<parity>	Description
3 (default)	space

Clarification

This command is supported for compatibility purpose and has no effect on ME.

It provides information on hardware capabilities.

+IFC TE-TA local flow control

Description	Command	Possible Response(s)
Set TE-TA local flow	+IFC=[<TA_by_TE>[,<TE_by_TA>]]	OK +CME ERROR: <err>
Get current value	+IFC?	+IFC: <TA_by_TE>,<TE_by_TA> OK
Get supported values	+IFC=?	+IFC: (list of supported <TA_by_TE>s),(list of supported <TE_by_TA >s) OK

Parameters

<TA_by_TE>	Description
0 (default)	No flow control
1	Software flow control. Not supported
2	Hardware flow control

< TA_by_TE>	Description
0	No flow control
1	Software flow control. Not supported
2 (default)	Hardware flow control

Clarification

This command configures the flow control mode.

+IFC parameters are saved into non-volatile memory by AT&W command and restored to default value by AT&F command.

Result codes

Verbose result code (command V1 set)	Numeric result code (command V0 set)	Type	Description
BUSY	7	Final	Busy signal detected
CONNECT	1	Intermediate	Connection has been established
CONNECT <text>	Manufacturer specific	Intermediate	As CONNECT but manufacturer specific <text> gives additional information (e.g. connection data rate)
ERROR	4	Final	Command not accepted
NO ANSWER	8	Final	Connection completion timeout
NO CARRIER	3	Final	Connection terminated
NO DIALTONE	6	Final	No dialtone detected
OK	0	Final	Acknowledges execution of a command line
+CRING			
RING	2	Unsolicited	Incoming call signal from network

Parameters

<text>	Numeric value
2400	10
4800	11
9600	12

<text>	Numeric value
14400	13
19200	15
28800	17
38400	19
48000	21
56000	23
64000	25
33600	27

5. Hayes Commands

Standard Hayes Commands

B Communication option

Description	Command	Possible Response(s)
Set communication option	B[<standard>]	OK ERROR

Parameters

<standard>	Description
0..99	standard

Clarification

This command is supported for compatibility purpose and has no effect on ME (simple response OK)

N Negotiate Handshake

Description	Command	Possible Response(s)
Set handshake	N[<option>]	OK ERROR

Parameters

<option>	Description
0..9	option

Clarification

This command is supported for compatibility purpose and has no effect on ME (simple response OK)

S1 Ring Count

Description	Command	Possible Response(s)
Read ring count for last MT call	S1?	<num> OK

Parameters

<num>	Description
0..255	Counts the number of rings detected on the line. It is cleared if a ring is not detected over an eight seconds time period. Default value: 0

Clarification

S1 parameter is saved into non-volatile memory by AT&W command and restored to default value by AT&F command.

S2 Escape character

Description	Command	Possible Response(s)
Set escape character	S2=<esc>	OK ERROR
Read escape character	S2?	<esc> OK

Parameters

<esc>	Description
43	Escape character 43 (i.e '+')

S11 DTMF Dialling Speed

Description	Command	Possible Response(s)
Set DTMF dialling speed	S11=<time>	OK ERROR

Parameters

<time>	Description
0..999	DTMF dialling speed

Clarification

This command is supported for compatibility purpose and has no effect on ME (simple response OK)

S95 Windows XP compatibility

Description	Command	Possible Response(s)
Windows XP compatibility	S95=<time>	OK ERROR

Parameters

<time>	Description
0..999	Windows XP compatibility

Clarification

This command is supported for compatibility purpose and has no effect on ME (simple response OK)

W Extended Result code

Description	Command	Possible Response(s)
Set extended result code	W<mode>	OK ERROR

Parameters

<mode>	Description
0	Only result code CONNECT supported

Advanced Hayes Commands

&K Extended Flow control option

Description	Command	Possible Response(s)
Set flow control	&K<mode>	OK ERROR

Parameters

<mode>	Description
0	Disable all USB flow control. Not supported
3	Enable USB bi-directional hardware flow control. Not supported.
4	Enable USB XON/XOFF flow control. Not supported.

&S DSR option

Description	Command	Possible Response(s)
Set DSR option	&S<override>	OK ERROR

Parameters

<override>	Description
0 (default)	Causes DSR signal to be active at all times
1	Causes DSR signal to be active after answer tone has been detected and inactive after the carrier has been lost

Clarification

Parameter stored by AT&W command.

&V Configuration profile

Description	Command	Possible Response(s)
Display active profile	&V[<profile>]	<profiles information> OK ERROR

Parameters

<profile>	Description
0 (default)	Display ACTIVE PROFILE, STORED PROFILE 0 and STORED PROFILE 1 information

&W Store Active profile

Description	Command	Possible Response(s)
Store active profile	&W[<profile>]	OK ERROR

Parameters

<profile>	Description
0 (default)	Store the current configuration in profile 0
1	Store the current configuration in profile 1

Clarification

Execution command stores the active <profile>. Two profiles are supported but they are equivalent.

Parameter stored by &W

Command	Parameter name	Displayed by &V
E	<echo>	Y
Q	<result>	Y
V	<format>	Y
X	<result>	Y
&C	<behavior>	Y
&D	<behavior>	Y
&S	<override>	Y
&R	<option>	Y
+CBST	<speed>	N
+CBST	<name>	N
+CBST	<ce>	N
+IFC	<TA_by_TE>	Y
+IFC	<TE_by_TA>	Y
&K	<mode>	Y
+FCLASS	<class>	Y

Command	Parameter name	Displayed by &V
+PSSLEEP	<mode>	N
S0	<num>	Y
S1	<num>	N
S3	<char>	Y
S4	<char>	Y
S5	<char>	Y
S7	<time>	Y
S8	<time>	Y
S10	<time>	Y

6. TIA IS-101 Commands

+VTS DTMF and Tone Generation

Description	Command	Possible Response(s)
Generate DTMF (Duration is set by +VTD)	+VTS="<DTMFn>,...,<DTMFn>"	OK +CME ERROR: <err>
Generate DTMF of frequencies <tone1> and <tone2>, lasting for a time <duration> (in 10 ms multiples).	+VTS=[<tone1>,<tone2>, <duration>]	OK +CME ERROR: <err>
Generate DTMF	+VTS="{<DTMFn>,<duration>}... {<DTMFn>,<duration>}"	OK +CME ERROR: <err>
Get supported values	+VTS=?	(list of supported <tone1>s),(list of supported <tone2>s) ,(list of supported <duration>s) OK

Parameters

<DTMFn>	Description
Character type	Character in the set 0..9, #,*,A..D

<tone1> <tone2>	Description
0	Manufacturer specific tone

<duration>	Description
0	Manufacturer specific duration

Clarification

This commands only works for speech calls in active state.

+VTD Tone Duration

Description	Command	Possible Response(s)
Set tone duration	+VTD=<n>	OK +CME ERROR: <err>
Get current duration	+VTD?	<n> OK
Get supported values	+VTD=?	(list of supported <n>s) OK

Parameters

<n>	Description
1..10	Tone duration

+VGR Receive Gain Selection

Description	Command	Possible Response(s)
Set receive gain	+VGR=<n>	OK +CME ERROR: <err>
Get receive gain	+VGR?	<n> OK
Get supported receive gain	+VGR=?	(list of supported <n>s) OK

Parameters

<n>	Description
1..10	Receive gain: 1 -34 dB 2 -29 dB 3 -24 dB 4 -19 dB 5 -14 dB (default) 6 -9 dB 7 -4 dB 8 +4 dB 9 +9 dB 10 +14 dB

Clarification

+VGR parameter is automatically saved into non-volatile memory.

+VGT Transmit gain selection

Description	Command	Possible Response(s)
Set transmit gain	+VGT=<n>	OK +CME ERROR: <err>
Get transmit gain	+VGT?	<n> OK
Get supported transmit gain	+VGT=?	(list of supported <n>s) OK

Parameters

<n>	Description
1..10	Transmit gain: 1 -6 dB 2 -2 dB 3 0 dB 4 +2 dB 5 +6 dB 6 +12 dB (default) 7 +18 dB 8 +24 dB 9 +30 dB 10 +36 dB

Clarification

Transmit gain setting takes effect after reset.

Transmit gain parameters are automatically saved into non-volatile memory.

+VIP Initialize voice parameter

Description	Command	Possible Response(s)
Set voice parameters	+VIP=<n>	OK +CME ERROR: <err>
Get supported voice parameters	+VIP=?	(list of supported <n>s) OK

Parameters

<n>	Description
0	Handset (7 levels of volume, main audio interface)
1	Handsfree (5 levels of volume, main audio interface)
2	Headset (5 levels of volume, secondary audio interface)

Clarification

The values 1 to 2 are automatically reset after a call (return to 0).

Levels of volume are accessible with AT+CLVL.

7. TIA578A Commands

General Commands

+FMI Manufacturer identification

Description	Command	Possible Response(s)
Get manufacturer ID	+FMI	<manufacturer> OK
Test if command is supported	+FMI=?	OK

Parameters

<manufacturer>	Description
String type	Read manufacturer identification (WAVECOM MODEM)

+FMM Model identification

Description	Command	Possible Response(s)
Get model ID	+FMM	<model> OK
Test if command is supported	+FMM=?	OK

Parameters

<model>	Description
String type	Read model identification (WISMO218)

+FMR Revision identification

Description	Command	Possible Response(s)
Get revision ID	+FMR	<revision> OK
Test if command is supported	+FMR=?	OK

Parameters

<revision>	Description
String type	Read revision identification (B02d00gg.WISMO218 250509)

Capabilities Identification and Control

+FCLASS Model identification

Description	Command	Possible Response(s)
Set class	+FCLASS=<class>	OK +CME ERROR: <err>
Get current class	+FCLASS?	+FCLASS: <class> OK
Get supported value	+FCLASS=?	+FCLASS: (list of supported <class>s) OK

Parameters

<class>	Description
0	Data mode
1	Fax class 1 (TIA-578-A) mode

+FTH HDLC transmit

Description	Command	Possible Response(s)
Set mode	+FTH=<mode>	OK +CME ERROR: <err>
Get current mode	+FTH?	+FTH: <mode> OK
Get supported modes	+FTH=?	+FTH: (list of supported <mode>s) OK

Parameters

<mode>	Description
3	V21 channel 2300 bps

Clarification

Set command is sent to ME only when link is online data mode.

This command is only relevant for in Fax mode.

+FRH HDLC receive

Description	Command	Possible Response(s)
Set mode	+FRH=<mode>	OK +CME ERROR: <err>
Get current mode	+FRH?	+FRH: <mode> OK
Get supported modes	+FRH=?	+FRH: (list of supported <mode>s) OK

Parameters

<mode>	Description
3	V21 channel 2300 bps

Clarification

Set command is sent to ME only when link is online data mode.

This command is only relevant in Fax mode.

+FTM Facsimile transmit

Description	Command	Possible Response(s)
Set mode	+FTM=<mode>	OK +CME ERROR: <err>
Get current mode	+FTM?	+FTM: <mode> OK
Get supported modes	+FTM=?	+FTM: (list of supported <mode>s) OK

Parameters

<mode>	Description
24, 48, 72, 96	24 V27ter 2400 bps 48 V27ter 4800 bps 72 V29 7200 bps 96 V29 9600 bps

Clarification

Set command is sent to ME only when link is online data mode.

9600 is always returned by read command because communication must begin at this speed.

+FRM Facsimile receive

Description	Command	Possible Response(s)
Set mode	+FRM=<mode>	OK +CME ERROR: <err>
Get current mode	+FRM?	+FRM: <mode> OK
Get supported modes	+FRM=?	+FRM: (list of supported <mode>s) OK

Parameters

<mode>	Description
24, 48, 72, 96	24 V27ter 2400 bps 48 V27ter 4800 bps 72 V29 7200 bps 96 V29 9600 bps

Clarification

Set command is sent to ME only when link is online data mode.

9600 is always returned by read command because communication must begin at this speed.

8. Proprietary AT Commands

Capabilities Identification and Control

#CLS Service class

Description	Command	Possible Response(s)
Set class	#CLS=<class>	OK +CME ERROR: <err>
Get current class	#CLS?	#CLS: <class> OK
Get the current mode	#CLS=?	#CLS: (list of currently available <class>s) OK

Parameters

<class>	Description
0 (default)	Data mode
1	Fax class 1 (TIA-578-A) mode

Clarification

This command has the same role and behaviour as +FCLASS command.

It is needed for Microsoft® agreement.

Flow Control Command

&R RTS/CTS option

Description	Command	Possible Response(s)
Set RTS/CTS option	&R<option>	OK ERROR

Parameters

<option>	Description
1 (default)	In sync mode, CTS is always ON (RTS transitions are ignored). In async mode, CTS will only drop if required by the flow control.

Clarification

This command selects how the modem controls CTS. CTS operation is modified if hardware flow control is selected (see &K command).

&R parameter is saved into non-volatile memory by AT&W command and restored to default value by AT&F command.

Manufacturer Tests Command

+CPOF Power off

Description	Command	Possible Response(s)
Switch off mobile	+CPOF	OK

Description

This command allows switching off the mobile. Note that "OK" result code will appear immediately if the command is accepted and power off will occur after that. Unexpected random characters may also be issued during switch off of MS.

*PSSSURC Supplementary Services notification

Description	Command	Possible Response(s)
Set mode	*PSSSURC=<mode>	OK +CME ERROR: <err>
Get current mode	*PSSSURC?	*PSSSURC: <mode> OK
Get supported modes	*PSSSURC=?	*PSSSURC: (list of supported <mode>s) OK

Description

This command is to configure the AT interface to give additional information through result code to TE when D command is entered with a SS string as parameter.

When <mode> parameter is enabled one or several intermediate result code are sent to provide additional information on SS operation.

Result code

Description	Result code
Successful SS operation	*PSSSURC: <SsCode>[,<BasicServiceCode>,<SsStatus>, <no_reply_cond_timer>,<ccbs_index>, <phone_number_ton_npi>, <phone_number_config>, <phone_number>,<sub_address_type>, <sub_address_authority_and_format_identifie>,<sub_address_data>[,<clir_option>]]
SS operation failure	*PSSSERR:<cause_select>,<cause>

One intermediate result code per <service code> is sent

Parameters

<mode>	Description
0 (default)	Disable sending of additional result code
1	Enable sending of additional result code

Clarification

Example: CFU interrogation for telephony service

ATD*#21*11#

*PSSSURC: 33,11,0,255,,129,0,,1,2,,1

OK

Ss_code = 33 → SPS_SC_CFU

BasicServicecode = 11 → SPS_BS_TELEPHONY

SsStatus = 0 → SPS_STATUS_DEACTIVATED

+PSSLEEP Power Management control

Description	Command	Possible Response(s)
Set sleep mode	+PSSLEEP=<mode>	OK +CME ERROR: <err>
Get current sleep mode	+PSSLEEP?	+PSSLEEP: <mode> OK
Get supported sleep modes	+PSSLEEP=?	+PSSLEEP: (list of supported <mode>s) OK

Parameters

<mode>	Description
0,1	0: The module doesn't go in sleep mode as long as DTR is set to high level (default value) 1: The module decides by itself (internal timing) when it goes in sleep mode

Clarification

Action command sets sleep mode for MT. If the command fails in an MT error, +CME ERROR: <err> is returned. Test command returns supported values.

In <mode>=1, any character sent on the UART will wake up the system, and then AT commands can be input normally. The module can also be waken up by a BREAK signal on the UART.

When the module is sleeping, it will set CTS to low.

+PSSLEEP parameter is saved into non-volatile memory by AT&W command. Default values are not restored by AT&F command.

SIM Toolkit Command and Result Codes

*PSSTKI SIM Toolkit interface configuration

Description	Command	Possible Response(s)
Set mode	*PSSTKI=<mode>	OK +CME ERROR: <err>
Get current mode	*PSSTKI?	*PSSTKI: <mode> OK +CME ERROR: <err>
Get supported modes	*PSSTKI=?	*PSSTKI: (list of supported <mode>s) OK +CME ERROR: <err>

Description

This command is to configure SIM toolkit by AT command.

Parameters

<mode>	Description
0	STK by AT command is deactivated, only ME's MMI will receive SIM toolkit notifications

<mode>	Description
1	STK by AT command is activated: SIM toolkit notification will first be sent to AT parser. If an AT channel is connected, *PSSTK URC will be sent, *PSSTK AT command has to be used to respond. If no AT channel is connected: ME's MMI will receive the notification

*PSSTK SIM Toolkit control

*PSSTK command is defined to support SIM toolkit by AT commands. Only part of SIM toolkit commands that interact with user or MMI can be controlled.

All other SIM toolkit mechanism such as terminal profile, SMS or CBM data download, call control or MO SMS control by SIM, event download and all command that does not require interaction with the user (or screen) are internally managed by the ME.

This command is implemented in ATCUST module and can be updated/modified.

Notification from SIM to user: PSSTK unsolicited result code

Description	Result code
Notification from SIM to user	*PSSTK: <notification type>,<parameter1>,…,<parameterN>

Parameters

<notification type>	Description
A string that represents the type of notification (proactive command name) received from the SIM. Some command requires the use of *PSSTK set command to send a response to the SIM.	
LANGUAGE NOTIFICATION	Sent on reception of APPI_STK_LANGUAGE_NOTIFICATION_IND
CONTROL BY SIM	Sent on reception of APPI_STK_CONTROL_BY_SIM_IND
REFRESH	Sent on reception of APPI_STK_REFRESH_IND
END CALL	Sent on reception of APPI_STK_END_CALL_IND
DISCONNECT	Sent on reception of APPI_CALL_ASYNC_DISCONNECT_IND
PROCESSING	Sent on reception of APPI_STK_PROCESSING_IND
END SESSION	Sent on reception of APPI_STK_END_SESSION_IND
ABORT SESSION	Sent on reception of APPI_STK_ABORT_SESSION_IND
NOTIFICATION	Sent on reception of APPI_STK_NOTIFICATION_IND Require use of *PSSTK set command to respond to SIM

<notification type>	Description
SETUP CALL	Sent on reception of APPI_STK_SETUP_CALL_IND Require use of *PSSTK set command to respond to SIM
DISPLAY TEXT	Sent on reception of APPI_STK_DISPLAY_TEXT_IND Require use of *PSSTK set command to respond to SIM
GET INKEY	Sent on reception of APPI_STK_GET_INKEY_IND Require use of *PSSTK set command to respond to SIM
GET INPUT	Sent on reception of APPI_STK_GET_INPUT_IND Require use of *PSSTK set command to respond to SIM
PLAY TONE	Sent on reception of APPI_STK_PLAY_TONE_IND Require use of *PSSTK set command to respond to SIM
SELECT ITEM	Sent on reception of APPI_STK_SELECT_ITEM_IND Require use of *PSSTK set command to respond to SIM
SETUP MENU	
REMOVE MENU	Sent on reception of APPI_STK_REMOVE_MENU_IND Require use of *PSSTK set command to respond to SIM
SETUP IDLE MODE TEXT	Sent on reception of APPI_STK_SET_UP_IDLE_MODE_TEXT_IND Require use of *PSSTK set command to respond to SIM

<parameteri>	Description
Integer or string type	Number of parameters in URC depends of the message.

Response from user to SIM: *PSSTK command

Description	Command	Possible Response(s)
Respond to SIM	*PSSTK=<reponse type>, <parameter1>,…,<parameterN>	OK +CME ERROR: <err>
Get supported response type	*PSSTK=?	*PSSTKI: (list of supported <response type>s) OK +CME ERROR: <err>

Parameters

<response type>	Description
A string that represents the type of response to be sent to SIM (terminal response or envelope). Some response correspond to answer to *PSSTK URC.	
MENU SELECTION	Send a APPI_STK_MENU_SELECTION_REQ (On reception of APPI_STK_MENU_SELECTION_CNF, OK is sent)
GET ITEM LIST	Call macro MC_STK_FIRST_ITEM and MC_STK_NEXT_ITEM to get the information of the last received SET UP MENU or SELECT ITEM command.
ALL CALLS DISCONNECTED	Send a APPI_STK_ALL_DISCONNECTED_REQ
USER ACTIVITY	Send a APPI_STK_USER_ACTIVITY_IND
IDLE SCREEN AVAILABLE	Send a APPI_STK_IDLE_SCREEN_AVAILABLE_IND
SETUP CALL TERMINATED	Send a APPI_STK_SETUP_CALL_TERMINATED_REQ
COMMAND REJECTED	Send a APPI_STK_COMMAND_RJT. Used to reject any URC that requires a response.
NOTIFICATION	Send a APPI_STK_NOTIFICATION_RSP
SETUP CALL	Send a APPI_STK_SETUP_CALL_RSP
DISPLAY TEXT	Send a APPI_STK_DISPLAY_TEXT_RSP
GET INKEY	Send a APPI_STK_GET_INKEY_RSP
GET INPUT	Send a APPI_STK_GET_INPUT_RSP
PLAY TONE	Send a APPI_STK_PLAY_TONE_RSP
SELECT ITEM	Send a APPI_STK_SELECT_ITEM_RSP
SETUP MENU	Send a APPI_STK_SETUP_MENU_RSP
REMOVE MENU	Send a APPI_STK_REMOVE_MENU_RSP
SETUP IDLE MODE TEXT	Send a APPI_STK_SET_UP_IDLE_MODE_TEXT_RSP

<parameteri>	Description
Integer or string type	Number of parameters in URC depends of message. Refer to STK SwISD and source code.

Use case

```
TE (PC)                                   ME
|                                         |
|    <--- *PSSTK: "DISPLAY TEXT",… ----    | <- unsolicited result code
|                                         |    received from SIM ToolKit
|    ---- *PSSTK: "DISPLAY TEXT",… --->    | <- answer to an unsolicited
|                                         |    result code
|    <------------- OK -----------         | <- AT command result
```

CPHS Proprietary Commands

*PSVMWN Voice Message Waiting Notification

Description	Command	Possible Response(s)
Set mode	*PSVMWN=<mode>	OK +CME ERROR: <err>
Get current mode	*PSVMWN?	*PSVMWN: <mode> OK +CME ERROR: <err>
Get supported modes	*PSVMWN =?	*PSVMWN: (list of supported <mode>s) OK +CME ERROR: <err>

Description

Set command enables/disables the presentation of notification result code from ME to TE

When <mode>=1, a Voice Message Waiting Indication (*PSVMWI) is sent to TE when notification is received (special SMS) from network or at switch on.

Description	Result code
Voice Message Waiting Indication	*PSVMWI: <line Id>,<status>[,<index>[,<NbMsgWaiting>]]

Parameters

<mode>	Description
0	Disable presentation of notification
1	Enable presentation of notification

<line Id>	Description
1	Line 1
2	Line 2 (Auxiliary line)
3	Data
4	Fax

<status>	Description
0	No message waiting
1	At least one message is waiting

<index>	Description
0..255	Record index in EF SMS if the received MWI message has been stored in SIM

<NbMsgWaiting>	Description
0..255	Number of message waiting on <line id>

*PSALS Alternate Line Service

Description	Command	Possible Response(s)
Select line for MO speech call	*PSALS=<Line Id>	OK +CME ERROR: <err>
Get current line	*PSALS?	*PSALS: <line Id> OK +CME ERROR: <err>
Get supported lines	*PSALS =?	*PSALS: (list of supported <line Id>) OK +CME ERROR: <err>

Description

Set command is used to select the line to be used for MO speech calls.

For MT (speech) calls, +CRING URC (refer +CRC command) indicates on which line the call is receive (*+CRING: VOICE* → default case = line 1, *+CRING: VOICE_AUX* → line 2.)

<line Id>	Description
1 (default)	Line 1
2	Line 2 (Auxiliary line)

*PSDCIN Diverted Call Indicator Notification

Description	Command	Possible Response(s)
Set mode	*PSDCIN=<mode>[,<line Id>]	[*PSDCIN: <line Id>,<status> [[...] <CR><LF>*PSDCIN: <line Id>,<status>]] OK +CME ERROR: <err>
Get current mode	*PSDCIN?	*PSCDIN: <mode> OK +CME ERROR: <err>
Get supported values	*PSDCIN=?	*PSDCIN: (list of supported <modes>),(list of supported <line Id>s)

Description

Set command enables/disables the presentation of a Diverted Call Indication (also know as CFU) result code from ME to TE.

When <mode>=2, status of <line Id> is requested. If <line Id> is not provided, query is requested for all lines.

When <mode>=1, Diverted Call Indication *PSDCI is sent to TE on reception of network notification. (Several result codes can be sent at the same time on reception of the notification).

Description	Result code
Diverted Call Indication	*PSDCI: <line Id>,<status>

Parameters

<mode>	Description
0	Disabled CFU notification presentation
1	Enabled CFU notification presentation
2	Query CFU status

<line Id>	Description
1	Line 1
2	Line 2 (Auxiliary line)
3	Data
4	Fax

<status>	Description
0	Not active
1	Active

*PSMBNB Mailbox Number

Description	Command	Possible Response(s)
Set mailbox number in SIM	*PSMBNB=<line Id>[,<number>,<type>[,<text>]]	OK +CME ERROR: <err>
Read mailbox numbers	*PSMBNB?	[*PSMBNB: <line Id>,<number>,<type>,<text> [[...] <CR><LF>*PSMBNB: <line Id>,<number>,<type>,<text>]] OK +CME ERROR: <err>
Get supported values	*PSMBNB=?	*PSMBNB: (list of supported <line Id>),(list of supported <type>)[,<nlength>][,<tlength>]

Description

The purpose of this command is not to replace +CSVM command but to offer more possibilities for Mailbox numbers settings (+CSVM command allows only voice mailbox settings, CPHS define one record per line).

Set command writes the mailbox number for <line id> in SIM.

If only <Line Id> is present in command, corresponding record is deleted in SIM.

Parameters

<line Id>	Description
1	Line 1

<line Id>	Description
2	Line 2 (Auxiliary line)
3	Data
4	Fax

<number>	Description
String type	Phone number of format <type>

<type>	Description
Integer type	Type of address (refer GSM 04.08 [8] subclause 10.5.4.7) ; default 145 when dialling string includes international access code character "+", otherwise 129

<text>	Description
String type	Field of maximum length <tlength> Character set as specified by +CSCS

<nlength>	Description
Integer type	Value indicating the maximum length of field <number>

<tlength>	Description
Integer type	Value indicating the maximum length of field <text>

*PSCSP Customer Service Profile

Description	Command	Possible Response(s)
Set command	*PSCSP	OK +CME ERROR: <err>
Read CSP	*PSCSP?	[*PSCSP: <service group code>, <status> [[...]<CR><LF>*PSCSP: <service group code>, <status>]] +CME ERROR: <err>

Description	Command	Possible Response(s)
Get supported values	*PSCSP=?	* PSCSP: (list of supported <service group code>s) OK +CME ERROR: <err>

Description

Command used to read the CSP file in SIM.

Set command has no effect (OK returned).

Parameters

<service group code>	Description
String type	Hexadecimal representation of a coding group as defined in CPHS recommendation (“01”..”09”, “C0”, “D5”)

<status>	Description
String type	Bitfield representation of each element of a service group (ex: "11000000”)

*PSINFN Information number

Description	Command	Possible Response(s)
Get information number entries	*PSINFN=<index1>[,<index 2]	[*PSINFN: <index1>,<number>,<type>,<text>,<Net Id>,<Prem Id>,<Level> [[...]<CR><LF>*PSINFN: <index2>,<number>,<type>,<text>,<Net Id>,<Prem Id>,<Level>] OK +CME ERROR: <err>
Read command	*PSINFN	OK +CME ERROR: <err>
Get supported values	*PSINFN=?	*PSINFN: (list of supported <index>s)[,<nlength>][,<tlength>] OK +CME ERROR: <err>

Description

Set command returns phonebook entries in location number range <index1>... <index2> from Information Number SIM file. If <index2> is left empty, only location <index1> is returned. If all queried locations are empty (but available), no information text lines may be returned (only an OK is returned). If listing fails in a ME error, +CME ERROR: <err> is returned.

Read command has no effect (returns OK)

Information number shall only be presented to TE if field InformationsNumbers of CSP file is 0xFF, use AT*PSCSP? to check Service Group D5. Otherwise +CME ERROR: <err> is returned.

Parameters

<index> <index1> <index2>	Description
0..255	Index of information number phonebook entry

<number>	Description
String type	Phone number of format <type>

<type>	Description
Integer type	Type of address

<text>	Description
String type	Field of maximum length <tlength> Character set as specified by +CSCS

<Net Id>	Description
Integer type	Representation of the Network specific indicator

<Prem Id>	Description
Integer type	Representation of Premium service indicator

<Level>	Description
Integer type	Representation of the level of the record (in the tree)

<nlength>	Description
Integer type	Value indicating the maximum length of field <number>

<tlength>	Description
Integer type	Value indicating the maximum length of field <text>

General Purpose Proprietary Commands

*PSPRAS Pin Remaining Attempt Status

Description	Command	Possible Response(s)
Set command	*PSPRAS	OK ERROR
Get remaining PIN attempts	*PSPRAS?	*PSPRAS: <pin1>,<puk1>,<pin2>,<puk2> OK ERROR
Get supported codes	*PSPRAS=?	*PSPRAS: (list of supported <code>s) OK ERROR

Description

This command is used to get the number of remaining PIN and PUK attempts.

Set command has no effect (returns OK).

Parameters

<pin1>	Description
0..3	Number of remaining attempts for PIN 1

<pin2>	Description
0..3	Number of remaining attempts for PIN 2

<puk1>	Description
0..10	Number of remaining attempts for PUK 1

<puk2>	Description
0..10	Number of remaining attempts for PUK 2

<code>	Description
SIM PIN1	PIN 1 identifier
SIM PIN2	PIN 2 identifier
SIM PUK1	PUK 1 identifier
SIM PUK2	PUK 2 identifier

*PSSEAV Service Availability

Description	Command	Possible Response(s)
Set mode	*PSSEAV=<mode>	OK +CME ERROR: <err>
Get current mode	*PSSEAV?	*PSSEAV: <mode> [<CR><LF>*PSREADY: <service>] [[…]<CR><LF>*PSREADY: <service>] OK +CME ERROR: <err>
Get supported modes	*PSSEAV=?	*PSSEAV: (list of supported <mode>s), (list of supported <service>s) OK +CME ERROR: <err>

Description

Set command enables/disables the presentation of notification result code from ME to TE. When <mode>=1, *PSREADY result code is sent to TE when <service> is available.

Read command is used to get current mode and to check which service are already available (*PSREADY is returned only for available services).

Description	Result code
Service ready	*PSREADY: <service>

Parameters

<mode>	Description
0	Disable notification presentation
1	Enable notification presentation

<service>	Description
0	Phone book service availability
1	SMS service availability
2	CBM service availability

Clarification

If a service becomes available before any AT channel is connected, *PSREADY notification will be buffered and sent as soon as the first AT channel connects.

+PSSREP Mobile start-up reporting

Description	Command	Possible Response(s)
Set mode	+PSSREP=<act>	OK +CME ERROR: <err>
Get current mode	+PSSREP?	+PSSREP: <act>,<stat> OK
Get supported modes	+PSSREP=?	+PSSREP: (list of supported <act>s) OK

Parameters

<act>	Description
0 or 1	Indicates if the module must send an unsolicited code during the startup. 0: The module doesn't send an unsolicited code (default value) 1: The module will send an unsolicited code *PSSUP

<stat>	Description
0 or 1	This code indicates the status of the module. 0: The module is ready to receive commands for the TE. No access code is required 1: The module is waiting for an access code. (The AT+CPIN? command can be used to determine it) 2: The SIM card is not present 3: The module is in “SIMlock” state 4: unrecoverable error 5: unknown state

Clarification

The module sends the unsolicited code once after the boot process *PPSUP: <stat>

The PPSUP notification will not be sent if the module is in autobaud mode and no bytes have been received from TE to adapt the serial link to the actual speed.

If the command fails in an MT error, +CME ERROR: <err> is returned. Test command returns supported values.

+PSSREP parameter is automatically saved into non-volatile memory.

The <act> parameter is restored to default value by AT&F command.

*PSCHRU Channel registration URC

Description	Command	Possible Response(s)
Set URC filter	*PSCHRU=<mask>	OK +CME ERROR: <err>
Get current channel filter	*PSCHRU?	*PSCHRU: <mask> OK +CME ERROR: <err>
Get supported masks	*PSCHRU=?	*PSCHRU: (list of supported <mask>s) OK +CME ERROR: <err>

Description

Set command is used to filter one or several type of URC on a channel. By default all URC types are enabled on a newly opened channel.

This command only applies on the channel it is submitted, other channels are not impacted. Depending of <mask> value, URC will or will not be broadcasted on the channel.

Parameters

<mode>	Description
0	No URC sent on the channel
1	Call related URC to be sent on the channel: RING, +CRING, +CCCM, +CCWV, +CCWA, +CLIP, +COLP, +CSSI, +CSSU, *PSCALL, *PSDCI, *PSCSC, *PSCN, *PSVTCS
2	SMS related URC to be sent on the channel: +CDS, +CMT, +CMTI, *PSMWI
4	CBM related URC to be sent on the channel: +CBM
8	ME status related URC to be sent on the channel: +CIEV, *PSCP, *PSNWID, *PSUTTZ,
16	Network registration related URC to be sent on the channel: +CREG, +CGREG, *PSNTRG
32	SS related URC to be sent on the channel: +CUSD
64	Initialisation related URC to be sent on the channel: *PSREADY
128	Debug related URC to be sent on the channel: *PSDBG
256	SIM toolkit related URC to be sent on the channel: *PSSTK

Clarification

To enable the display of URC SMS (2) and CALL (1) and to forbid the display of the others on a channel, choose 2 and 1 parameter, i.e send:

AT*PSCHRU=3

OK

+PSTAT tool detection enable

Description	Command	Possible Response(s)
Trig restart with tool detection	+PSTAT=<param>	OK +CME ERROR: <err>

Parameters

<param>	Description
Integer type	Useless parameter

Clarification

The set command enables the tool presence detection by the module and provokes an intended watchdog reset.

When restarting after the watchdog reset, the module sends 'I' (0x49) on UART to enquire for a tool.

Further reboots (intended or not) does not provoke tool detection procedure.

*PSRDBS Radio band settings

Description	Command	Possible Response(s)
Set radio bands	*PSRDBS=<mode>[,<GSM band>]	OK +CME ERROR: <err>
Get current values	*PSRDBS?	*PSRDBS: <GSM band> OK
Get supported values	*PSRDBS=?	*PSRDBS: (list of supported <mode>s),(list of supported <GSM band>s) OK

Description

Set command is used to set the radio band(s).

When <mode>=0, band settings are taken into account only at next switch on. However, the read command will display the band settings to be applied after next switch on.

When <mode>=1, a stack restart is performed to select immediately the requested settings.

Parameters

<mode>	Description
0	Set radio bands, will be taken into account at next switch on
1	Set radio bands, a stack restart is performed to take into account the new selected bands.

<GSM band>	Description
1	GSM 850. Not supported
2	GSM 900

<GSM band>	Description
4 (default)	E-GSM
8 (default)	DCS 1800
16	PCS 1900. Not supported

Bit field type parameter; to set several bands sum up the values

Clarification

Example 1:

To set GSM 900 & DCS 1800:

AT*PSRDBS=1,10

OK

Example 2:

To set E-GSM and PCS 1800:

AT*PSRDBS?

*PSRDBS: 4

OK

AT*PSRDBS=0,12

OK

AT*PSRDBS?

*PSRDBS: 12

OK

With <mode>=0, "12" will only take effect after the module reboots. Note that the current registered band would still be "4" and that the read command will only display the new band setting after the module has rebooted.

*PSRDBS parameters are automatically saved into non-volatile memory.

*PSADC A/D Convert info

Description	Command	Possible Response(s)
Read A/D value	*PSADC=<Adc>,<Meastime>	*PSADC: <AdcValue>,<Adc>,<Meastime>,<TxPower> OK +CME ERROR: <err>

Description

This command will return AdcValue,RequestedAdc,MeasTime,BurstPower.

Parameters

<Adc>	Description
0	Battery voltage (Vbatt)
3	Reserved
4	Auxilliary ADC (AUX_ADC0)

<Meastime>	Description
1	During transmit burst
2	Outside transmit burst
3	No constraint on transmit burst

<AdcValue>	Description
Integer	Voltage value read by ADC

<TxPower>	Description
Integer	Tx power value applied during Tx burst if <MeasTime>=1, otherwise 0

+PSRIC RI behaviour

Description	Command	Possible Response(s)
Set RI behaviour	+PSRIC=<RImask>,<RIshape>	OK +CME ERROR: <err>
Get RI behaviour	+PSRIC?	+PSRIC: <RImask>,<RIshape> OK +CME ERROR: <err>
Get supported values	+PSRIC=?	+PSRIC: (list of supported <RImask>s),(list of supported <RIshape>s) OK +CME ERROR: <err>

Description

This command sets the Ring Indicator (RI) behaviour.

Parameters

<RImask>	Description
0	No RI indication
1	RI indication on incoming calls
2	RI indication on SMS reception
4	RI indication on Cell Broadcast Messages (CBM) reception
8	RI indication on Supplementary Service (SS) reception
16	RI indication on +CIEV event reception
31	All values

Bit field type parameter; to set several RI conditions, sum up the values

<RIshape>	Description
0	RI is indicated by a low pulse
1	RI is indicated by a continuous low level

+WMGPIO GPIO access

Description	Command	Possible Response(s)
Set GPIO access	+WMGPIO=<IO>,<cde>	if <cde>=2 +WMGPIO: <IO>,<status> OK else OK +CME ERROR: <err>
Get GPIO access	+WMGPIO?	OK
Get supported GPIO access	+WMGPIO=?	+WMGPIO: (list of supported <IO>s),(list of supported <cde>s) OK

Description

This command allows reading or writing a GPIO.

Parameters

<IO>	Description
1	GPIO1
3	GPIO3
5	GPIO5

<cde>	Description
0	Reset the selected GPIO
1	Set the selected GPIO
2	Request the status of the selected GPIO

<status>	Description
0	GPIO is low
1	GPIO is high

Clarification

GPIO configuration is not stored in memory. The current configuration is lost with a reset.

Be aware that this command doesn't change the reset state of the GPIO.

+WMGPIOCFG GPIO configuration

Description	Command	Possible Response(s)
Set GPIO configuration	+WMGPIOCFG=<IO>,<dir>,<pull mode>	OK +CME ERROR: <err>
Get GPIO configuration	+WMGPIOCFG?	+WMGPIOCFG: <IO>,<dir>,<pull mode> [+WMGPIOCFG: <IO>,<dir>,<pull mode>...] OK
Get supported GPIO configuration	+WMGPIOCFG=?	+WMGPIOCFG: (list of supported <IO>s),(list of supported <dir>s),(list of supported <pull mode>s) OK

Description

This command allows setting a GPIO as input or output.

Parameters

<IO>	Description
1	GPIO1
3	GPIO3
5	GPIO5

<dir>	Description
0	output
1	input

<pull mode>	Description
0	pull down
1	pull up
2	no pull

Clarification

The GPIO configuration is not stored in memory. The current configuration is lost with a reset.

If GPIO set as output, user cannot select pull mode as “no pull”.

+WMPWM PWM and buzzer configuration

Description	Command	Possible Response(s)
Set PWM configuration	+WMPWM=<output>,<operation>,[<period>],[<dutycycle>]	OK +CME ERROR: <err>
Get PWM configuration	+ WMPWM?	+WMPWM:<output>,<operation>,<period>,<dutycycle> [+WMPWM:<output>,<operation>,<period>,<dutycycle> …] OK
Get supported PWM configuration	+ WMPWM=?	+WMPWM:(list of supported <output>s),(list of supported <operation>s),(list of supported <period>s),(list of supported <dutycycle>s) OK

Description

This command allows setting PWM or buzzer configuration.

Parameters

<output>	Description
0	PWM0
1	PWM1
2	Buzzer

<operation>	Description
0	Turn off
1	Turn on
2	Always high level

<period>	Description
0 … 126 (when <output> is PWM0 or PWM1)	0: PWM always low level 1 ... 126: PWM period as n+1 TSYSCLK/8 (TSYSCLK/8 =1/(26MHz/8) = 307ns)
0 … 1024 (when <output> is buzzer)	Buzzer frequency as SYSCLK/(<period>*2*64) (ex: if <period> = 203, then frequency is 26MHz/(203*2*64) = 1KHz)

<dutycycle>	Description
0 … 100	dutycycle percentage

Clarification

Buzzer does not have “Always high level” operation.

Default values of period and duty-cycle for PWM0 and PWM1 are 63, 50.

Default values of period and duty-cycle for buzzer are 250, 100.

+SIDET Sidetone

Description	Command	Possible Response(s)
Set sidetone	+SIDET=<level>	OK +CME ERROR: <err>

Description	Command	Possible Response(s)
Get sidetone value	+SIDET?	+SIDET: <level> OK
Get supported sidetone values	+SIDET=?	+SIDET: (list of supported <level>s) OK

Description

This command allows setting the sidetone level.

Parameters

<level>	Description
0-8	Sidetone level: 0 -26 dB 1 -22 dB 2 -18 dB 3 -14 dB 4 -10 dB 5 -6 dB 6 -2 dB 7 +2 dB 8 +6 dB (default)

Clarification

Sidetone setting takes effect after reset.

Sidetone parameters are automatically saved into non-volatile memory.

+WMECHO Echo Cancellation and Noise Reduction

Description	Command	Possible Response(s)
Set AEC/NR	+WMECHO=<eState>,<nState>	OK +CME ERROR: <err>
Get AEC/NR status	+WMECHO?	+WMECHO: <eState>,<nState> OK
Get supported AEC/NR values	+WMECHO=?	+WMECHO: (list of supported <eState>s),(liste of supported <nState>s) OK

Description

This command allows enabling or disabling the Acoustic Echo Cancelletion (AEC) and the Noise Reduction (NR).

Parameters

<eState>	Description
0 (default)	AEC is off
1	AEC is on

<nState>	Description
0 (default)	NR is off
1	NR is on

Clarification

AEC/NR setting takes effect after reset.

AEC/NR parameters are automatically saved into non-volatile memory.

+WSVN IMEI Software Version Number

Description	Command	Possible Response(s)
Read IMEISVN	+WSVN	+WSVN: <IMEISVN> OK

Description

This command allows reading the IMEI Software Version Number (IMEISVN).

Parameters

<IMEISVN>	Description
Integer type	IMEISVN (2 digits)

+WMSN Serial number

Description	Command	Possible Response(s)
Read serial number	+WMSN	Serial Number: <SN> OK

Description	Command	Possible Response(s)
Test if command is supported	+WMSN=?	OK

Description

This command allows reading the WISMO218 serial number.

Parameters

<SN>	Description
Alphanumeric type	Serial number (15 characters)

Call and Network Proprietary Commands

*PSCSCN Call state change notification

Description	Command	Possible Response(s)
Select notification presentation mode	*PSCSCN=<mode>	OK +CME ERROR: <err>
Get the current mode	*PSCSCN?	*PSCSCN: <mode> OK

Description

This command allows presentation of information about CS call states as well as audio or in-call notifications related to current call.

This command does note replace +CLCC command. TE is notified whenever the state of a call changes, this avoid TE to use polling mechanism with +CLCC command to know the states of each call.

When <mode>=0, set command disables both the presentation of call state change URC (*PSCSC) and call notification URC (*PSCN)

When <mode>=1, set command enables the presentation of call state change URC (*PSCSC) every time the state of a call changes.

When <mode>=2, set command enables both the presentation of call state change URC (*PSCSC) and call notification URC (*PSCN) every time audio or in-call notification occurs (in-band, SS-notify…).

Description	Result code
Call state change	*PSCSC: <Call Id>,<State>,<Status>,[<Number>],[<type>], [<Line Id>],[<CauseSelect>],[<Cause>],[<Bearer>]

The optional fields of the URC are filled only when information is available (i.e depending of the state of the call), otherwise they are left empty.

Description	Result code
Call notification	*PSCN: <Call Id>,<Notification>

Parameters

<mode>	Description
0	Disable presentation of all notifications
1	Enable presentation of *PSCSC
2	Enable presentation of *PSCSC and *PSCN

<Call Id>	Description
0	Call Id not yet assigned (alerting MT call)
1..7	Call Id representing a CS speech call
>8	Call Id representing a CS data call

<State>	Description
0	MO call SETUP (no control by SIM)
1	MO call SETUP WITH CONTROL BY SIM (accepted)
2	MO call SETUP ERROR (control by SIM rejected or other problem)
3	MO call PROCEED
4	MO call ALERT (at distant)
5	MO call CONNECT (with distant)
6..9	RFU
10	MT call SETUP
11	MT call SETUP ACCEPTED (Bearer capabilities accepted by the ME)

<State>	Description
12	MT call SETUP REJECTED (Bearer capabilities rejected by the ME)
13	MT call ALERT
14	MT call CONNECT (ME has successfully accepted the call)
15	MT call CONNECT ERROR (ME was not able to accept the call)
16..19	RFU
20	Call DISCONNECT BY NETWORK
21	Call DISCONNECT BY USER
22	Call REJECT BY USER
23..29	RFU
30	MO call SETUP – Call initiated by SAT (SET UP CALL command received)
31	MO call PROCEED – Call initiated by SAT (SET UP CALL command received)
32	MO call ALERT (at distant) – Call initiated by SAT (SET UP CALL command received)
33	MO call CONNECT (with distant) – Call initiated by SAT (SET UP CALL command received)

<Status>	Description
0	Call in ACTIVE state
1	Call in HOLD state (applicable only for speech calls, either MO or MT)
2	Call in MULTIPARTY ACTIVE state (applicable only for speech calls, either MO or MT)
3	Call in MULTIPARTY HOLD state (applicable only for speech calls, either MO or MT)

<Number>	Description
String type	Phone number (same as in +CLIP)

<type>	Description
Integer type	Type of address (same as in +CLIP)

<Line Id>	Description
1	Line 1
2	Line 2 (auxiliary line)

<Cause Select>	Description
Integer type	Cause selection

<Cause>	Description
Integer type	Cause

<Bearer>	Description
String type	Hexadecimal representation format of bearer capability (for data calls only).

<Notification>	Description
SS notification by network (Partly described in Rec. 24.080)	
1	Incoming call is a forwarded call
2	Incoming call has been forwarded
4	Outgoing call has been forwarded
5	Call is waiting at distant
6	Call is held by distant
7	Call is retrieved by distant
8	Call is in multiparty
9	CLIR suppression rejected
129	Incoming call is a deflected call
132	Outgoing call has been deflected call
Audio notification	
16	Audio on
17	Audio off
18	In band information

<Notification>	Description
19	Audio mute
SS status. (Partly described in Rec. 24.080 & Rec. 29.002)	
32	All forwarding SS
33	Call forwarding unconditional
40	All conditional forwarding SS
41	Call forwarding on mobile subscriber busy
42	Call forwarding on no reply
43	Call forwarding on mobile subscriber not reachable
144	All barring SS
145	Barring of outgoing calls
146	Barring of all outgoing calls
147	Barring of outgoing international calls
148	Barring of outgoing international calls expect those directed to home PLMN
153	Barring of incoming calls
154	Barring of all incoming calls
155	Barring of incoming calls when roaming outside home PLMN country
Notification pertaining to the call (refer rec. 24.008 - § 10.5.4.20)	
48	User suspended
49	User resumed
50	Bearer change
Alerting patterns (refer rec. 24.008 - § 10.5.4.26)	
80	Alerting pattern level 0
81	Alerting pattern level 1
82	Alerting pattern level 2
84	Alerting pattern category 1
85	Alerting pattern category 2
86	Alerting pattern category 3

<Notification>	Description
87	Alerting pattern category 4
88	Alerting pattern category 5

Clarification

This command uses information available at APPI interface (application i/f). AT parser does not interface directly with protocol stack so it does not have immediate access to L3 messages, this means that <state> does not match L3 messages exactly as they are defined in 24.008 recommendation.

• SIM toolkit- SET UP CALL

Values 30..33 for <state> are used when a SET UP CALL proactive command has been received from the SAT. This call is initiated internally in the ME by STK. *PSCSCS notification will be broadcasted as URC: the MO call has been initiated by STK, no AT channel is associated to the call.

Examples:

MO speech alerting at distant and initiated on line 1

*PSCSCS: 1, 4, 1,,, 1, , ,

MO speech call connected to "11111111" and active on line 1

*PSCSCS: 1, 5, 1, "1111111", 129, 1, , ,

MT data call connected to "123456" and active on line 1, BC list = A28881211563A6

*PSCSCS: 8, 14, 1, "123456", 129, 1, , , "A28881211563A6"

+CNAP Command: Calling Name Presentation

Description	Command	Possible Response(s)
Control +CNAP URC	+CNAP=<n>	OK +CME ERROR: <err>
Get status of CNAP	+CNAP?	+CLIR: <n>,<m> OK +CME ERROR: <err>
Get supported values	+CNAP=?	+CNAP: (list of supported <n>s) OK +CME ERROR: <err>

Parameters

<n>	Description
0	+CNAP notification is disabled
1	Enabled unsolicited result code: +CNAP: <name>,<validity>

<m>	Description
0	Network does not provide the CNAP service
1	Network provides the CNAP service
2	Unknown (e.g. no network, etc.)

<validity>	Description
0	Name presentation allowed
1	Presentation restricted
2	Name unavailable
3	Name presentation restricted

Clarification

CNAP (Calling Name Presentation) is a supplementary service provided by the network. +CNAP command enables or disables the presentation of the name provided by the network.

*PSFSNT Field strength notification

Description	Command	Possible Response(s)
Select notification mode	*PSFSNT=<mode>	OK +CME ERROR: <err>
Get the current mode	*PSFSNT?	PSFSNT: <mode> OK

Description

This command allows presentation of field strength notification.

Set command enable (or disable) the presentation of *PSFS each time field strength increase or decrease of 5 dBm.

Description	Result code
Field strength notification	*PSFS: <field strength>

Parameters

<mode>	Description
0	Disable presentation of notification
1	Enable presentation of notification

<field strength>	Description
0	GSM RX level is less than -110 dBm
1..62	GSM RX level is less than -109..-48 dBm
63	GSM RX level is greater than -48 dBm
255	GSM RX level is unavailable

Clarification

The values defined are not the same as for +CSQ command.

*PSCSSC Call successful control

Description	Command	Possible Response(s)
Set mode	*PSCSSC=<mode>	OK +CME ERROR: <err>
Get current mode	*PSCSSC?	*PSCSSC: <mode> OK

Description

This command controls the emission of the result code for MO speech successful set-up.

If “Connected line identification presentation” supplementary service is activated (refer to +COLP), result code for ATD command will be sent to TE when call is connected to the called party (successful call set-up).

If “Connected line identification presentation” supplementary service is not activated (refer to +COLP), result code for ATD can be sent as soon as call set-up is started or after call is connected to the called party (after successful call set-up).

Set command allows selection of <mode> for MO speech call result code.

If user sets <mode>=1 when +COLP is also activated, ERROR will be returned. Mode will remain to 0.

Parameters

<mode>	Description
0 (default)	OK is returned only when call is connected to the remote party
1	OK is returned when call setup is started.The user is not informed of call successful connection to remote party. If the call fails, NO ANSWER or NO CARRIER will be sent after OK.

*PSCCDN Call connection and disconnection notification

Description	Command	Possible Response(s)
Set mode	*PSCCDN=<mode>	OK +CME ERROR: <err>
Get current mode	*PSCCDN?	*PSCCDN: <mode> OK
Get supported values	*PSCCDN=?	*PSCCDN: (list of supported <mode>s),(list of supported <status>s) OK

Description

This command allows presentation of information about connection or disconnection of a CS call (either MT or MO). This URC allow TE to exactly know which call is being connected or disconnected (NO CARRIER URC is not sufficient to discriminate calls id)

Set command enables or disables the presentation of notification result code from ME to TE.

When <mode>=1, *PSCALL result code is sent to TE on connection or disconnection of call <call id>

Description	Result code
Call notification	*PSCALL: <call Id>,<status>[,<number>]

Parameters

<mode>	Description
0	Disable notification
1	Enable notification

<call id>	Description
0	Waiting call (alerting, no call id assigned yet)

1..7	Speech call ID
> 8	Data call id

<status>	Description
0	Disconnected
1	Connected

<number>	Description
String type	Phone number (when <status>=1)

Clarification

Special case: to inform that current waiting call has been disconnected: *PSCALL: 0,0 is sent.

The +CLCC command can be used to get more information about a specific call.

SIERRA WIRELESS
HEART OF THE WIRELESS MACHINE®